



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
1		WG9981340113	HOWO REAR OIL SEAL
2		WG9981320133	HOWO AXLE LOCK NUT
3		WG9981320123	HOWO OIL SEAL
4		WG9981320106	HOWO AXLE LOCK NUT
5		WG9925610030	HOWO WHEEL COVER
6		WG9925590053	HOWO ENGINE SUPPORT
7		WG9925550003	HOWO FUEL TANK CAP
8		WG9925520223	HOWO BALANCE SHAFT OIL SEAL




# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
9		WG9925470045	HOWO PITMAN ARM
10		WG9925190002	HOWO A7 RUBBER HOSE
11		WG9918530001	HOWO RADIATOR
12		WG9725593016	HOWO ENGINE SUPPORT REAR
13		WG9725580100 WG9725580100	HOWO Start relay
14		WG9725542045 WG9725542045	HOWO EXHAUST BUTTERFLY VALVE
15		WG9725542041-1	HOWO EXHAUST BUTTERFLY VALVE
16		WG9725542041/1 WG9725542041/1	HOWO EXHAUST BUTTERFLY VALVE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
17		WG9725542041	HOWO EXHAUST BRAKE VALVE
18		WG9725540053	HOWO FLEXIBLE HOSE
19		WG9725538237	HOWO SINOTRUCK Rubber pipe; auto spare parts; engine accessories; Cooling System
20		WG9725538236	HOWO Rubber hose
21		WG9725530603 WG9725530603	HOWO AIR CONDICIONER FAN GUARD GRILL
22		WG9725526205	HOWO BALL JOINT BEARING
23		WG9725520727	HOWO LIMIT BLOCK
24		WG9725520286-1	HOWO TRUCK LEAF SPRING REAR



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
25		WG9725520286+004 WG9725520286-004	HOWO TRUCK LEAF SPRING REAR ; 4th PC 25*90
26		WG9725520073	HOWO FRONT RIGHT LEAF SPRING
27		WG9725520072+003 WG9725520072-C	HOWO LEAF SPRING 16*90 FRONT ; 3rd PC - 1800mm long
28		WG9725520072+002 WG9725520072-B	HOWO LEAF SPRING 16*90 FRONT ; 2nd PC - 1700mm long
29		WG9725520072+001 WG9725520072-A	HOWO LEAF SPRING 16*90 FRONT ; 1st PC - 1800mm long
30		WG9725520072 WG9725520072	HOWO LEAF SPRING 16*90 FRONT assy 10PCS/SET
31		WG9725310010	HOWO UNIVERSAL JOINT
32		WG9725240208 WG9725240208	HOWO GEAR SHIFT SYSTEM



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
33		WG9725240202	HOWO SHIFTING CABLE ASSEMBLY
34		WG9725240113	HOWO GEAR SHIFT CABLE
35		WG9725240111	HOWO GEAR SHIFT CABLE
36		WG9725240108	HOWO Manipulator assembly
37		WG9725240107/3	HOWO Manipulator assembly
38		WG9725240107 WG9725240107	HOWO OPERATOR ASSY.
39		WG9725193918	HOWO DUCT FOR AIR INTAKE SYSTEM
40		WG9725190933	HOWO RUBBER HOSE




# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
41		WG9725190918/1	HOWO CABIN INLET PIPE ASSEMBLY
42		WG9725190904	HOWO AIR INLET PIPE
43		WG9725190200	HOWO AIR FILTER ASSEMBLY
44		WG9725190180	HOWO The air filter assembly
45		WG9725190151/1	HOWO AIR FILTER STRAP
46		WG9725190150	HOWO OIL BATH TYPE AIR FILTER ASSEMBLE
47		WG9725190144	HOWO INLET AIR PIPE
48		WG9725190055	HOWO OIL BATH AIR CLEANER ASSY



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
49		WG9725190007	HOWO INLET CLAMP for WG9725190007
50		WG9725160300	HOWO CLUTCH PLATE
51		WG9719930315 WG9719930315	HOWO BRACKET FOR LEFT REAR MUDGUARD
52		WG9719930313 WG9719930313	HOWO BRACKET FOR RIGHT REAR MUDGUARD
53		WG9719820007	HOWO HOSE
54		WG9719820006	HOWO HIGH PRESSURE HOSE
55		WG9719820005/1	HOWO SINOTRUCK High pressure hose
56		WG9719810002	HOWO Right combination taillight





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
57		WG9719810001	HOWO Left Combined taillight
58		WG9719790006 WG9719790006	HOWO REAR FOG LAMP
59		WG9719790002 WG9719790002	HOWO INTERNAL RH
60		WG9719720006	HOWO Right front combination lamp
61		WG9719720005	HOWO Left front combination lamp
62		WG9719584001/2	HOWO LIGHT SWITCH
63		WG9719580018	HOWO Combined instrument gauge
64		WG9719530231	HOWO RADIATOR





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
65		WG9719470228	HOWO STEERING BOX
66		WG9719320105-3	HOWO CLUTCH MASTER CYLINDER PUSH ROD
67		WG9719240117 WG9719240117	HOWO SUPPORT BAR
68		WG9719240116 WG9719240116	HOWO POSITIONING BAR
69		WG9719240113	HOWO SHIFT CABLE
70		WG9719240111	HOWO GEAR SHIFT CABLE
71		WG9719230027	HOWO HIGH PRESSURE TUBE
72		WG9719190033	HOWO SINOTRUCK Rubber damping block assembly




# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
73		WG9719190002 WG9719190002	HOWO AIR FILTER SUPPORT
74		WG9718710003	HOWO AIR HORN SOLENOID VALVE
75		WG9718710002	HOWO The basin shaped electric horn
76		WG97187100013 WG97187100013	HOWO MAGNETIC VALVE
77		WG9700290020	HOWO QH70 PTO FOR HW19710 FAST GEAR BOX
78		WG9700240002	HOWO SOLENOID
79		WG9900241005 WG9700240001	HOWO SHIFT HANDLE
80		WG9632530333	HOWO EXPANTION TANK 9L



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
81		WG9231342070-RH	HOWO BRAKE HUB ASSEMBLY RH
82		WG9231342070-LH	HOWO BRAKE HUB ASSEMBLY LH
83		WG9231342068	HOWO BRAKE LINING 14 holes; rivets 10*22; 8pcs/set; NAO material
84		WG9231320272/1	HOWO DIFERENCIAL ASSEMBLY
85		WG9231320224	HOWO PLANETARY GEAR GASKET
86		WG9231320163	HOWO DIFERENCIAL HOUSING
87		WG9231320153	HOWO PLANETARY GEAR WASHER
88		WG9200340068	HOWO brake lining






# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
89		WG9130583117/1	HOWO Combined switch
90		WG9114520042	HOWO BALL BEARING
91		WG9114160030 WG9114160030	HOWO CLUTCH BEARING VALEO
92		WG9114160020	HOWO CLUTCH PLATE
93		WG9112530333-2	HOWO Expansion tank
94		WG9112530333	SINOTRUK HOWO Parts - WG9112530333 STRW Expansion Tank Assembly
95		WG9100760100	HOWO power switch
96		WG9100760002 WG9100760002	HOWO BATTERY PIPE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
97		WG9100720105/2	HOWO SINOTRUK HEAD LIGHT RH
98		WG9100720105/1	HOWO SINOTRUK HEAD LIGHT LH
99		WG9100680068	HOWO T7H RUBBER BEARING
100		WG9100570014	HOWO STOP FUEL CYLINDER
101		WG9100520065	HOWO Spring Pin
102		WG9100520024	HOWO GUIDE SPRING
103		WG9100440029	HOWO BRAKE LINING 9 holes; rivets 10*22; 8pcs/set; NAO material
104		WG9100440027	HOWO BRAKE LINING 8 holes; rivets 10*22; 8pcs/set; NAO material



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
105		AZ9719240006 WG9100368471	HOWO DRYER ASSY.
106		WG9100340017	HOWO CAMSHAFT BUSH
107		WG9014520311	HOWO BALANCE SHAFT COVER
108		WG901410125 WG901410125	HOWO PROPELLER SHAFT
109		WG9012340021	HOWO OIL-PROOFING COVER
110		WG9012250031	HOWO SLOTTED NUT
111		WG9003999725 WG9003999725	HOWO NEEDLE ROLL BEARING
112		WG9003990428 WG9003990428	HOWO NEEDLE ROLLER BEARING



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
113		WG9003990424 WG9003990424	HOWO NEEDLE ROLLER BEARING
114		WG900360520 WG900360520	HOWO TOTAL BRAKE VALVE
115		WG900360180-3 WG900360180-3	HOWO CONTROL VALVE
116		WG900360165	HOWO CONTROL VALVE
117		WG9003323221 WG9003323221	HOWO COUNTERSHAFT BEARING
118		WG9000520079	HOWO BUSHING
119		WG9000360180	HOWO CONTROL VALVE
120		WG9000360165	HOWO HAND BRAKE VALVE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
121		WG9000360115	HOWO Drain valve
122		WG9000270002	HOWO AIR HORN
123		WG7925538237	HOWO RUBBER HOSE
124		WG69100520034	HOWO A7 SUPPORT
125		WG2229210076	HOWO SINOTRUCK HD Strut assembly
126		WG2229210041	HOWO GOLD GEAR SHIFT BAR ASSEMBLY
127		WG222921004 WG222921004	HOWO SUPPORT ROD
128		WG2229020020 WG2229020020	HOWO LOCK RING





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
129		WG220325003	HOWO DOUBLE H VALVE
130		WG2203250010	HOWO TRUCK AIR CONTROL VALVE
131		WG2203250003	HOWO DOUBLE H VALVE
132		WG2203240005	HOWO GEARBOX OIL PUMP
133		WG2203100108 WG2203100118	HOWO CLUTCH HUB
134		WG1680590095	HOWO RUBBER SUPPORT
135		WG1664440101	HOWO HYD. LOCK
136		WG1664340008/2	HOWO TRUCK CAB DOOR DIGITAL LOCK



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
137		WG1664340005	HOWO A7 OUT DOOR HANDLE RH
138		WG1664340004	HOWO A7 OUT DOOR HANDLE LH
139		WG1664240008	HOWO SIDE BUMPER PANEL - LH
140		WG1664240007	HOWO SIDE BUMPER PANEL - RH
141		WG1664240005	HOWO A7 BUMPER
142		WG1662770010	HOWO DOWNVIEW MIRROR
143		WG1661740022	HOWO TRUCK WIPER LINKAGE
144		WG1661740020	HOWO WIPER MOTOR




# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
145		WG1651430010	HOWO RUBBER BUSHING
146		WG1644870002	HOWO Sun visor
147		WG1642870231	HOWO Sun visor
148		WG1642820002 WG1642820002	HOWO AIR CONDITIONER WITH ELECTRO AIR INTAKE
149		WG1642770003	HOWO Right rearview mirror
150		WG1642770001	HOWO Left rearview mirror
151		WG1642741008	HOWO WIPER MOTOR
152		WG1642741001-1	HOWO Wiper device



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
153		WG1642741008 WG1642741001	HOWO WIPER MOTOR
154		WG1642440383	HOWO SHOCK ABSORBER
155		WG1642440382	HOWO REAR SHOCK ABSORBER
156		WG1642440088	HOWO SHOCK ABSORBER FOR CABIN
157		WG1642440081	HOWO Shock absorber
158		WG1642440075	HOWO HOSE
159		WG1642440071	HOWO HOSE
160		WG1642350004	HOWO SINOTRUCK right corner of the window glass





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
161		WG1642350003	HOWO SINOTRUCK left corner of the window glass
162		WG1642340033	HOWO Inner open lid handle
163		WG1642340032 + WG1642340033	HOWO INTERNAL HANDLE WITH COVER
164		WG1642340032	HOWO Inner opening handle
165		WG1642340001	HOWO DOOR HANDLE
166		WG1642330004/2	HOWO Right Window regulator
167		WG1642330003	HOWO LEFT Window regulator
168		WG1642330001	HOWO HANDLE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
169		WG1642240033 WG1642240033	HOWO BOTTOM STEP RIGHT
170		WG1642240032 WG1642240032	HOWO BOTTOM STEP LEFT
171		WG1642230104	HOWO RIGHT Fender
172		WG1642230103	HOWO Left Fender
173		WG1642230013 WG1642230013	HOWO WHEEL FENDER RIGHT
174		WG1642230012 WG1642230012	HOWO WHEEL FENDER LEFT
175		WG1642230004	HOWO REAR WHEEL FENDER RIGHT
176		WG1642230003	HOWO REAR WHEEL FENDER LEFT






# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
177		WG16421100241 WG16421100241	HOWO AIR SPRING
178		WG1642110020	HOWO A POLE GARNISH RIGHT
179		WG1642110019	HOWO A POLE GARNISH LEFT
180		WG1642110016	HOWO FRONT COVER SUPPORT
181		WG1642110002	HOWO Left air guide cover
182		WG1642110001	HOWO Right air guide cover
183		WG1641240114	HOWO The right pedal
184		WG1641240113	HOWO The left pedal



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
185		WG1641230052	HOWO Frant right wheel rear fender
186		WG1641230051	HOWO Frant left wheel rear fender
187		WG1640777020 WG1640777020	HOWO REAR VIEW MIRROR RH
188		WG1640777010 WG1640777010	HOWO REAR VIEW MIRROR LH
189		WG1630840322 WG1630840322	HOWO CONTROL PANEL
190		WG1034121032	HOWO NOX SENSOR
191		612630010055 WCG22BK-EL10 61800010125	STEYR HOWO WEICHAI WP12 WD618 ENGINE LINER
192		61500040047 VV058BK-OSC0J	HOWO CRANKSHAFT SEAL REAR











# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
193		WG9925822002 VV058BK-LPP0	HOWO HYD. LIFT PUMP
194		VG2600111137 VG2600111137	HOWO EXHAUST MANIFOLD
195		VG2600111136 VG2600111136	HOWO EXHAUST MANIFOLD
196		VG2600060313	HOWO PULLEY
197		VG2600010489	HOWO FUEL PIPE COVER
198		VG1560130070 VG1560130070	HOWO AIR COMPRESSOR ASSY
199		VG1560118229	HOWO TURBO CHARGER
200		VG1560118227D VG1560118227D	HOWO TURBOCHARGER





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
201		VG1540110066 VG1540110066	HOWO TURBO CHARGER
202		VG154008311	HOWO FILTER
203		VG1540040022A VG1540040022A	HOWO OIL SEAL
204		VG1540020004	HOWO FLYWHEEL
205		VG14080740A	HOWO Diesel filter (coarse)
206		VG14080739A	HOWO Diesel filter (fine)
207		VG14040065 VG14040065	HOWO COVER
208		VG1246110040	HOWO TURBO CHARGER



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
209		VG1246110021	HOWO TURBO CHARGER
210		VG1246060022	HOWO PULLEY
211		VG1246060005 VG1246060005	HOWO TENSIONER
212		VG1246060001	HOWO PULLEY
213		VG1246040017	HOWO INJECTOR BUSH
214		VG1099110012/2	HOWO D10 CHARGER
215		VG109604001A	HOWO INJECTOR SLEEVE
216		VG1092080009	HOWO FUEL FILTER



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
217		6PK736 VG1062090001 17*350	HOWO BELT 17*350
218		VG1047110103/1	HOWO RUBER HOSE
219		TG53715800005/1	HOWO COMBINATION SWITCH
220		TG16058200049	CNHTC HOWO CONDENSOR
221		TG16053600001	HOWO AIR HORN ASSEMBLY
222		61500010319 STG24BK-EL10	STEYR HOWO WD615 ENGINE LINER
223		321WT06 STD07BK-EL10	STEYR HOWO WD612 ENGINE LINER
224		61500010344 ST058BK-EL10	STEYR HOWO TRUCK ENGINE LINER



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
225		Q151B1440	HOWO BOLT
226		200-03100-6423 MNB43BK-CLH1	HOWO MC13/ MAN D2066,D2676 CYLINDER HEAD
227		KC140040021	HOWO OVERHAULING GASKET
228		K808840 K808840	HOWO 1/2G. CLUTCH BODY
229		K808835 K808835	HOWO CG. NEEDLE CAGE
230		VG1500010125 HWG24BK-THW0	HOWO WD615 THRUST WASHER
231		VG1540050016/17 HWG24BK-RK20	HOWO WD615 ROCKER ARM
232		WG1560030040 HWG24BK-PTR1	HOWO WD615 PISTON RINGS



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
233		VG1540030006/07/08 HWG24BK-PTR0	HOWO WD615 PISTON RINGS
234		VG1540030003 HWG24BK-PRN0	HOWO WD615 PISTON
235		VG1560030013 HWG24BK-PIN0	HOWO WD615 PISTON PIN
236		VG1540050009 HWG24BK-PHR0	HOWO WD615 PUSH ROD
237		VG1560080305 HWG24BK-IJT2	HOWO WD615 INJECTOR
238		VG1540080017 HWG24BK-IJT0	HOWO WD615 INJECTOR
239		WG9725190002 HWG24BK-IAP0	HOWO WD615 INLET AIR PIPE
240		VG1500050032 HWG24BK-HL00	HOWO WD615 HYD. LIFT



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
241		HWG24BK-GT41	HOWO D12 / 380 GASKET FULL SET
242		AZ61560010701 HWG24BK-GT40	HOWO 371 GASKET FULL SET
243		VG1540040015A HWG24BK-GT31	HOWO 380 CYL HEAD GASKET
244		VG1540040015 HWG24BK-GT30	HOWO 380/ WD615 CYL HEAD GASKET
245		VG1540080101 HWG24BK-FP10	HOWO WD615 FUEL PUMP
246		VG1540050014 HWG24BK-EV1X	HOWO WD615 ENGINE VALVE EX.
247		VG1540050015 HWG24BK-EV1W	HOWO WD615 ENGINE VALVE IN.
248		VG1540010006 HWG24BK-EL10	HOWO WD615 ENGINE LINER



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
249		VG1540030015/16 HWG24BK-EB30	HOWO WD615 LOWER ENGINE CON ROD BEARING STD
250		VG1540010008 HWG24BK-EB11	HOWO WD615 UPPER ENGINE MAIN BEARING STD
251		VG1540010007 HWG24BK-EB10	HOWO WD615 UPPER ENGINE MAIN BEARING STD
252		VG1540030014 HWG24BK-CNR0	HOWO WD615 CONNECTING ROD
253		VG1500050097 HWG24BK-CMT1	HOWO WD615 CAMSHAFT
254		VG1540050004 HWG24BK-CMT0	HOWO WD615 CAMSHAFT
255		VG1540080016 HWG24BK-CMP0	HOWO WD615 COMMON RAIL PIPE
256		61560020029 HWG24BK-CKS0	HOWO WD615 CRANKSHAFT





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
257		VG1560030077 HWG24BK-B030	HOWO 371 CON ROD BUSH
258		VG154003000 HWB47BK-PTN0	HOWO 371/ 380 PISTON/PIN/CLIP
259		HWB42BK-TCA0 VG75601182270	HOWO GT42 TURBO CHARGER
260		VG1500060050 HW866BK-WP00 VG1500060050	HOWO WD615 WATER PUMP ASSY.
261		WG9003884160 HW866BK-WNT0 WG9003884160	HOWO WD615 WHEEL NUT
262		99012340029 HW866BK-WLG0	HOWO WD615 WHEEL GASKET
263		190003326531 HW866BK-WLBI 190003326531	HOWO WD615 WHEEL BEARING FRONT (OUT 32310)
264		1-34-172-010 HW866BK-WKL0 1-34-172-010	HOWO WD615 WORKING LAMP



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
265		WG1642230107 HW866BK-WIGDJA	HOWO WD615 LEFT WING REAR PART ASSY.
266		WG1641230051 HW866BK-WIGDJ WG1641230051	HOWO WD615 LEFT WING REAR PART
267		WG1642230108 HW866BK-WIGCJA	HOWO WD615 RIGHT WING REAR PART ASSY.
268		WG1641230052 HW866BK-WIGCJ WG1641230052	HOWO WD615 RIGHT WING REAR PART
269		VG1560060012 HW866BK-WIC0 VG1560060012	HOWO WD615 WATER INLET CONNECTOR
270		AZ9112340123 HW866BK-WHSJ	HOWO WD615 REAR WHEEL SCREW with Nut
271		WG9000361402 HW866BK-WDV0 WG9000361402	HOWO WD615 WATER DRAIN VALVE
272		WG168059095 HW866BK-WDS0I	HOWO WEDGE SUPPORT FRONT



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
273		AZ9725590031 HW866BK-WDS0	HOWO WD615 WEDGE SUPPORT
274		HW866BK-VRK0	HOWO WD615 TRAILER VALVE REPAIR KIT
275		61500050025 HW866BK-VCL0 61500050025	HOWO WD615 VALVE CONE
276		VG1500130017 HW866BK-VBT2 VG1500130017	HOWO V-BELT
277		VG2600020253 HW866BK-VBT1 8PK1050	HOWO WD615 V-BELT
278		VG1500090066 HW866BK-VBT0 6PK783	HOWO WD615 V-BELT
279		AZ9725529272 HW866BK-VBR0	HOWO WD615 V-BRACE ROD TOQUE ROD
280		VG1560030034 HW866BK-USB0	HOWO WD615 UPPER SLEEVE BEARING



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
281		VG1500010600 HW866BK-UOD0 VG1500010600	HOWO WD615 UPPER OIL DIPSTIC
282		WG9232520232 HW866BK-UBTJ WG9232520232	HOWO WD615 U BOLT REAR
283		199000520109 HW866BK-UBTI1 199000520109	HOWO WD615 U BOLT FRONT
284		AZ9112520312 HW866BK-UBTI AZ9112520312	HOWO WD615 U BOLT FRONT
285		WG9130583117/1 HW866BK-TSS0 WG9130583117/1	HOWO WD615 TURN SIGNAL SWITCH
286		VG1560060069 HW866BK-TSBP VG1560060069	HOWO WD615 TENSIONER BEARING PULLEY
287		WG1630820313 HW866BK-TS11 WG1630820313	HOWO WD615 TEMPERATURE SENSOR
288		VG614090067J HW866BK-TS10 VG614090067J	HOWO WD615 WATER TEMPERATURE SENSOR



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
289		WG9000360171 HW866BK-TLC1 WG9000360171	HOWO WD615 TRAILER COUPLING
290		WG9000360170 HW866BK-TLC0 WG9000360170	HOWO WD615 TRAILER COUPLING
291		WG9000360525 HW866BK-TCV0	HOWO WD615 TRAILER CONTROL VALVE
292		HW866BK-TCK0	HOWO WD615 TURBOCHARGER REPAIR KIT
293		WG9725538043 HW866BK-TCH0	HOWO WD615 INTER COOLER HOSE
294		WG9112540015 HW866BK-TCG0 WG9112540015	HOWO OM615 TURBOCHARGER GASKET
295		199000440029 HW866BK-TBL0 199000440029	HOWO WD615 T BRAKE LINING
296		WG1500130017 HW866BK-TBE0 WG1500130017	HOWO WD615 BELT



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
297		DZ9114520174 HW866BK-SZR0 DZ9114520174	HOWO WD615 STABILIZER ROD
298		WG9100680055 HW866BK-SZP0 WG9100680055	HOWO WD615 STABILIZER PLATE
299		WG1644870031/1 HW866BK-SWSC WG1644870031/1	HOWO WDM615 SIDE WIND SHEET RIGHT
300		9725520366 HW866BK-SVR0 9725520366	HOWO WD615 SCREW FOR V-BRACE ROD
301		AZ9719680006 HW866BK-STZJ AZ9719680006	HOWO WD615 STABILIZER C REAR
302		AZ9719680003 HW866BK-STZ1 AZ9719680003	HOWO WD615 STABILIZER C
303		AZ1642440021 HW866BK-STZ0	HOWO WD615 STABILIZER SHOCK ABSORBER
304		WG1641240113 HW866BK-STLD1 WG1641240113	HOWO WD615 LEFT STEP BOW BOTTOM



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
305		WG1642240111 HW866BK-STLD WG1642240111	HOWO WD615 LEFT STEP BOW BOTTOM
306		WG1642240112 HW866BK-STLC WG1642240112	HOWO WD615 RIGHT STEP BOW BOTTOM
307		WG9725477107 HW866BK-STH1 WG9725477107	HOWO WD615 STEERING HOSE
308		WG9100470082 HW866BK-STH0 WG9100470082	HOWO WD615 STEERING HOSE
309		6150090029 HW866BK-STA1 6150090029	HOWO WD615 STARTER MOTOR for Styer
310		VG1560090001 HW866BK-STA0	HOWO WD615 STARTER MOTOR
311		AZ9130583019 HW866BK-SSC0 AZ9130583019	HOWO WD615 STARTER SWITCH BY KEY
312		2159333001 HW866BK-SS10 2159333001	HOWO WD615 SLIDING SLEEVE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
313		WG9725580100 HW866BK-SRR1 WG9725580100	HOWO WD615 START RELAY
314		WG9100583049 HW866BK-SRR0 WG9100583049	HOWO WD615 START RELAY
315		14750 HW866BK-SRG1 14750	HOWO WD615 STOP RING
316		C01021 HW866BK-SRG0 C01021	HOWO WD615 STOP RING
317		VG190320035 HW866BK-SRC0 VG190320035	HOWO WD615 SEALING RING CLIP
318		2159328002 HW866BK-SR11 2159328002	HOWO WD615 SYNCHRONIZER RING
319		1297304402 HW866BK-SR10 1297304402	HOWO WD615 SYNCHRONIZER RING
320		AZ9719230009 HW866BK-SPR2 AZ9719230009	HOWO WD615 SPRING





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
321		AZ9100340012 HW866BK-SPR1	HOWO WD615 SPRING
322		199112340049 HW866BK-SPR0	HOWO WD615 SPRING
323		AZ9725520276 HW866BK-SPP2 AZ9725520276	HOWO WD615 SUPPORT
324		WG9725120276 HW866BK-SPP1 WG9725120276	HOWO WD615 SUPPORT
325		AZ1642430097 HW866BK-SPP0 AZ1642430097	HOWO WD615 SUPPORT
326		16463 HW866BK-SPA0 16463	HOWO WD615 SPACER
327		WG9100583058 HW866BK-SMS1 WG9100583058	HOWO WD615 SPEEDOMETER SENSOR
328		WG9100583056 HW866BK-SMS0 WG9100583056	HOWO WD615 SPEEDOMETER SENSOR






# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
329		WG1642770001 HW866BK-SMRD AZ1642771001	HOWO 615 SIDE MIRROR LH
330		WG1642770003 HW866BK-SMRC AZ1642771002	HOWO 615 SIDE MIRROR RH
331		VG1600770005/2 HW866BK-SMR0 VG1600770005/2	HOWO WD615 SIDE MIRROR
332		WG9100070006 HW866BK-SLS0 WG9100070006	HOWO WD615 STOP SWITCH LAMP
333		WG9100340056 HW866BK-SLRD	HOWO WD615 BRAKE ADJUSTION ARM(SLACK ADJUSTER)LEFT
334		WG9100340057 HW866BK-SLRC	HOWO WD615 BRAKE ADJUSTION ARM(SLACK ADJUSTER) RIGHT
335		VG609070080 HW866BK-SIRO VG609070080	HOWO WD615 SEALING RING
336		73431011 HW866BK-SFS0 73431011	HOWO WD615 SHAFT SEAL



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
337		VG1092080052 HW866BK-SFE1 VG1092080052	HOWO OM615 SEPARATE FILTER
338		WG9725550002-1 HW866BK-SFE0 WG9725550002-1	HOWO WD615 SEPARATE FILTER
339		VG2600150106 HW866BK-SEW3 VG2600150106	HOWO WD615 SEALING WASHER
340		VG2600080004 HW866BK-SEW2 VG2600080004	HOWO WD615 SEALING WASHER
341		VG9003080003 HW866BK-SEW1 VG9003080003	HOWO WD615 SEALING WASHER
342		VG2600080200 HW866BK-SEW0 VG2600080200	HOWO WD615 SEALING WASHER
343		HW866BK-SCK0	HOWO WD615 SHIFT CYLINDER REPAIR KIT
344		HW866BK-SBK0	HOWO WD615 STEERING BOX REPAIR KIT



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
345		WG1642440085 HW866BK-SARJ	HOWO WD615 SHOCK ABSORBER REAR
346		AZ1642440081/82 HW866BK-SARIB	HOWO WD615 FRONT SHOCK ABSORBER NEW MODEL
347		AZ1642440027/28 HW866BK-SARIA	HOWO WD615 FRONT SHOCK ABSORBER OLD MODEL
348		WG1642430280 HW866BK-SARI0	HOWO SHOCK ABSORBER FRONT
349		WG1642430025 HW866BK-SARI	HOWO WD615 FRONT SHOCK ABSORBER
350		WG9100680001 HW866BK-SAR0	HOWO WD615 SHOCK ABSORBER
351		HW866BK-RVR0	HOWO WD615 RELAY VALVE REPAIR KIT
352		199100680066 HW866BK-RUB2	HOWO RUBBER BEARING



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
353		199100680068 HW866BK-RUB1	HOWO WD615 RUBBER BEARING
354		199100680067 HW866BK-RUB0	HOWO WD615 RUBBER BEARING
355		WG9000360524 HW866BK-RLV0	HOWO WD615 RELAY VALVE
356		19223326167 HW866BK-RLB0 19223326167	HOWO WD615 ROLLER BEARING
357		HW866BK-RK01	HOWO OM615 REPAIR KIT FOR CLUTCH MASTER CYLINDER
358		HW866BK-RK0	HOWO OM615 REPAIR KIT FOR CLUTCH MASTER CYLINDER
359		189000340068 HW866BK-RIV0 189000340068	HOWO WD615 RIVET
360		VG2600060446 HW866BK-RFN0	HOWO WD615 RING FAN



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
361		WG9725530011 HW866BK-RDT1	HOWO WD615 RADIATOR R/F
362		WG9725530231 HW866BK-RDT0	HOWO WD615 RADIATOR
363		61800060161 HW866BK-RDS0	HOWO WD615 RADIATOR SHROUD
364		WG1680590095 HW866BK-RBS0	HOWO WD615 RUBBER SUPPORT
365		WG1642330003 HW866BK-R020	HOWO WD615 LEFT WINDOW REGULATOR
366		WG1642230004 HW866BK-R010 WG1642230004	HOWO WD615 RIGTH WINDOW REGULATOR
367		VG1560030040 HW866BK-PTR2	HOWO WD615 PISTON RING
368		VG1560030050 HW866BK-PTR1 VG1560030050	HOWO WD615 PISTON RING



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
369		VG1560030045/47/7 HW866BK-PTR0 VG1560030045/47/7	HOWO WD615 PISTON RINGS
370		VG1560037011 HW866BK-PTN2	HOWO 371 PISTON
371		VG1560030011 HW866BK-PTN1	HOWO WD615 47 PISTON (OIL COOLING GROOVE)
372		VG1560030010 HW866BK-PTN0	HOWO WD615 87 PISTON
373		WG9000361401 HW866BK-PTC0 WG9000361401	HOWO WD615 PRESSURE TEST CONNECTOR
374		199000340027 HW866BK-PRR0 199000340027	HOWO WD615 PRESSURE ROLLER
375		HW866BK-PRK0	HOWO WD615 PUSH ROD REPAIR KIT
376		WG880680027 HW866BK-PLT0 WG880680027	HOWO WD615 PLATE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
377		1880440032 HW866BK-PBSI 1880440032	HOWO WD615 FRONT BRAKE SHOE SPRING PIN
378		AZ1630840072 HW866BK-OWP0	HOWO WD615 OUTLET WATER PIPE
379		WG9719230014 HW866BK-OTC0	HOWO WD615 OIL TANK OF CLUTCH
380		VG1800070051 HW866BK-OST0 VG1800070051	HOWO WD615 OIL STRAINER
381		WG9112340114 HW866BK-OS71	HOWO WD615 REAR WHEEL SEAL
382		WG9112340113 HW866BK-OS70	HOWO WD615 REAR WHEEL SEAL
383		VG1560079025 HW866BK-ORP2 VG1560079025	HOWO WD615 OIL RETURN PIPE
384		VG1560079003 HW866BK-ORP1 VG1560079003	HOWO WD615 OIL RETURN PIPE





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
385		VG1560070025 HW866BK-ORP0 VG1560070025	HOWO WD615 OIL RETURN PIPE
386		WG9725230040 HW866BK-ORC1 WG9725230040	HOWO WD615 OPERATING CYLINDER (DIA90, DIA22)
387		WG9725230041 HW866BK-ORC0	HOWO WD615 OPERATING CYLINDER (DIA120, DIA25)
388		79100710003 HW866BK-OPS1 79100710003	HOWO WD615 PRESSURE SWITCH
389		VG1500090060 HW866BK-OPS0 VG1500090060	HOWO WD615 OIL PRESSURE SWITCH
390		WG9719530207 HW866BK-OPC0	HOWO WD615 OUTLET AIR PIPE HOSE CONNECTOR
391		VG1500070021 HW866BK-OP10	HOWO WD615 OIL PUMP ASSY
392		VG1560070004 HW866BK-OLP1	HOWO WD615 OIL SUPPLY PIPE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
393		VG1560070002 HW866BK-OLP0	HOWO WD615 OIL SUPPLY PIPE
394		VG1500010047 HW866BK-OISJ VG1500010047	HOWO WD615 OIL SEAL REAR
395		VG1500010037 HW866BK-OISF VG1500010037	HOWO WD615 OIL SEAL FRONT
396		614070055 HW866BK-OIG0 614070055	HOWO WD615 OIL PUMP GASKET
397		WG9000360509 HW866BK-OFV0 WG9000360509	HOWO WD615 OVERFLOW VALVE
398		LF4017 HW866BK-OFE1 LF4017	HOWO WD615 OIL FILTER
399		61000070005 HW866BK-OFE0 VG61000070005	HOWO WD615 OIL FILTER
400		WG9719530208 HW866BK-OAP0	HOWO WD615 OUTLET AIR PIPE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
401		VG2600010659 HW866BK-NZL0 VG2600010659	HOWO WD615 OIL INJECTION NOZZLE
402		VG1560080305 HW866BK-NZJ1 VG1560080305	HOWO TRUCK NOZZLE INJECTOR
403		VG1560080276 HW866BK-NZJ0 VG1560080276	HOWO TRUCK NOZZLE INJECTOR
404		VG1560080305 HW866BK-NZH0 VG1560080305	HOWO WD615 NOZZLE HOLDER C
405		JS180A-1701036 HW866BK-NUT0 JS180A-1701036	HOWO WD615 NUT
406		WG9000360507 HW866BK-NRV0 WG9000360507	HOWO WD615 NON RETURN VALVE
407		VG1560080276 HW866BK-NIJ0 VG1560080276	HOWO WD615 NOZZLE INJECTOR
408		WG9719710004 HW866BK-MGV0	HOWO WD615 SOLENOID VALVE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
409		WG9725540060 HW866BK-MFR1 WG9725540060	HOWO WD615 MUFFLER
410		WG9725540010 HW866BK-MFR0	HOWO WD615 MUFFLER
411		AZ9100520015 HW866BK-LSB0 AZ9100520015	HOWO WD615 LEAF SPRING "U" BOLT
412		AZ1560070026 HW866BK-LOR0 AZ1560070026	HOWO WD615 LUBRICATING OIL REVERSAL
413		AZ9112410055 HW866BK-KKED AZ9112410055	HOWO WD615 LEFT KNUCKLE ASSEMBLY
414		AZ9112410056 HW866BK-KKEC AZ9112410056	HOWO WD615 RIGHT KNUCKLE ASSEMBLY
415		AZ1630840073 HW866BK-IWP0	HOWO WD615 INLET WATER PIPE
416		VG14080082 HW866BK-IWA0 VG14080082	HOWO WD615 INJECTOR WASHER



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
417		WG971980080015 HW866BK-ITP0 WG971980080015	HOWO WD615 INSTRUMENT PANEL
418		19694 HW866BK-ISCO 19694	HOWO WD615 INPUT SHAFT FOR CLUTCH SHAFT
419		HW866BK-IPK0	HOWO WD615 FIX KIT OF INJECTION PUMP
420		VG1560130035 HW866BK-IPC0	HOWO WD615 INTAKE PIPE CONNECTOR
421		VG1560080276 HW866BK-IJT1	HOWO TRUCK INJECTOR
422		R61540080017/A HW866BK-IJT0	HOWO TRUCK INJECTOR
423		61560110051 HW866BK-ICP0	HOWO WD615 INTER COOLER PIPE
424		WG1642440101 HW866BK-HYL0	HOWO WD615 HYD. LOCK



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
425		HW866BK-HVK0	HOWO WD615 HAND BRAKE VALVE REPAIR KIT
426		WG9619470080 HW866BK-HP00 WG9619470080/4	HOWO WD615 HYDRAULIC PUMP
427		190003179785 HW866BK-HOP9	HOWO WD615 HOSE PIPE
428		190003179784 HW866BK-HOP8	HOWO WD615 HOSE PIPE
429		190003179781 HW866BK-HOP7	HOWO WD615 HOSE PIPE
430		WG9100360184 HW866BK-HOP6	HOWO WD615 HOSE PIPE
431		WG9719820007 HW866BK-HOP5	HOWO WD615 HIGH PRESSURE HOSE PIPE
432		WG9719820006 HW866BK-HOP4	HOWO WD615 HIGH PRESSURE HOSE PIPE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
433		WG9719820005 HW866BK-HOP3	HOWO WD615 HIGH PRESSURE HOSE PIPE
434		WG9114530139 HW866BK-HOP2	HOWO WD615 HOSE PIPE
435		WG1642440071 HW866BK-HOP10	HOWO WD615 HOSE
436		WG9114530138 HW866BK-HOP1	HOWO WD615 HOSE PIPE
437		WG1620840060 HW866BK-HOP0	HOWO WD615 HOSE PIPE
438		VG190003989336 HW866BK-HOC2	HOWO WD615 HOSE CLAMP
439		1900039989306 HW866BK-HOC1	HOWO WD615 HOSE CLAMP
440		1900043989301 HW866BK-HOC0	HOWO WD615 HOSE CLAMP



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
441		WG9719820001 HW866BK-HHP0	HOWO WD615 HYD. HAND PUMP
442		WG9719820002 HW866BK-HDC0	HOWO WD615 HYD. CYLINDER
443		AZ9731590020 HW866BK-HDB0	HOWO WD615 HOLDING BRAKET
444		WG9719360030/3 HW866BK-HBV1 WG9719360030/3	HOWO WD615 HAND BRAKE VALVE FOR TRAILER
445		WG9000360522 HW866BK-HBV0 WG9000360522	HOWO WD615 HAND BRAKE VALVE
446		VG1560110111 HW866BK-GT60 VG1560110111	HOWO WD615 EX. GASKET
447		VG1540040049 HW866BK-GT37 VG1540040049	HOWO WD615 CYL HEAD GASKET
448		AZ9112320184 HW866BK-GT36 AZ9112320184	HOWO WD615 CYL HEAD GASKET (OUT)





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
449		AZ9112320030 HW866BK-GT35 AZ9112320030	HOWO WD615 CYL HEAD GASKET (INNER)
450		VG2600110457 HW866BK-GT34 VG2600110457	HOWO WD615 CYL HEAD GASKET
451		AZ9719540019 HW866BK-GT33 AZ9719540019	HOWO WD615 GASKET
452		VG14010070 HW866BK-GT31 VG14010070	HOWO WD615 GASKET
453		VG14010040 HW866BK-GT30 VG14010040	HOWO WD615 GASKET
454		WG9719240112 HW866BK-GSC0	HOWO WD615 GEAR SHIFT CABLE
455		WG1642716005 HW866BK-GRC0 WG1642716005	HOWO WD615 GLASS REAR CAB
456		AZ1500070020 HW866BK-GOP1 AZ1500070020	HOWO WD615 OIL PUMP GEAR



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
457		AZ1500070019 HW866BK-GOP0 AZ1500070019	HOWO WD615 OIL PUMP GEAR
458		JS150T-1701031 HW866BK-G010 JS150T-1701031	HOWO WD615 MAIN SHAFT GEAR
459		VG1560087018 HW866BK-FUL2 VG1560087018	HOWO WD615 FUEL LINE
460		VG1560087017 HW866BK-FUL1 VG1560087017	HOWO WD615 FUEL LINE
461		VG1500080095 HW866BK-FUL0 VG1500080095	HOWO WD615 FUEL LINE
462		WG9725550009 HW866BK-FTS0	HOWO WD615 FUEL TANK STRAP 400L
463		WG9725550300 HW866BK-FTK1	HOWO WD615 FUEL TANK 300L
464		WG9725550006 HW866BK-FTK0	HOWO WD615 FUEL TANK 400L



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.

TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
465		WG1642110013 HW866BK-FPN0	HOWO WD615 FRONT COVER
466		R61540080101 HW866BK-FP10 R61540080101	HOWO TRUCK FUEL PUMP
467		VG1560080278A HW866BK-FII0 VG1560080278A	HOWO WD615 INJECTION PIPE
468		VG1560080012 HW866BK-FFE1S VG1540080211	HOWO WD615 FUEL FILTER with sensor
469		VG1560080012-7 HW866BK-FFE1	HOWO WD615 FUEL FILTER
470		VG1540080311 HW866BK-FFE0	HOWO WD615 FUEL FILTER
471		WG1642230105 HW866BK-FE0D	HOWO WD615 LEFT WHEEL FENDER
472		WG1642230106 HW866BK-FE0C	HOWO WD615 RIGHT WHEEL FENDER



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
473		WG9112550213 HW866BK-FCP0 WG9112550213	HOWO WD615 FUEL CAP
474		WG9719720005 HW866BK-FCLD1 WG9719720005	HOWO WD615 FRONT COMBINATORY LAMP LEFT
475		WG9719720015 HW866BK-FCLD WG9719720015	HOWO WD615 FRONT COMBINATORY LAMP LEFT
476		WG9719720006 HW866BK-FCLC1 WG9719720006	HOWO WD615 FRONT COMBINATORY LAMP RIGHT
477		WG9719720016 HW866BK-FCLC WG9719720016	HOWO WD615 FRONT COMBINATORY LAMP
478		VG1047080009 HW866BK-FCF0 VG1047080009	HOWO WD615 FUEL FILTER CUP
479		WG9719360005 HW866BK-FBV0 WG9719360005	HOWO WD615 FOOT BRAKE VALVE
480		WG1642240001 HW866BK-FBU1	HOWO FRONT BUMPER



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
481		WG1642240002 HW866BK-FBU0	HOWO WD615 FRONT BUMPER
482		199000440027 HW866BK-FBL0 199000440027	HOWO WD615 T FRONT BRAKE LINING
483		AZ1630840014 HW866BK-FAN0 AZ1630840014	HOWO WD615 FAN
484		DZ9114530260 HW866BK-EXT1	HOWO EXPANSION TANK
485		WG9719530260 HW866BK-EXT0	HOWO WD615 EXPANSION TANK
486		VG1560040031 HW866BK-EV20	HOWO WD615 ENGINE VALVE GUIDE
487		VG1560051001 HW866BK-EV1X	HOWO WD615 ENGINE VALVE EX.
488		HW866BK-EV1WX	HOWO WD615 ENGINE VALVE IN. + EX.





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
489		61560050042 HW866BK-EV1W 61560050042	HOWO WD615 ENGINE VALVE IN.
490		HW866BK-ERK0	HOWO WD615 ENGINE REPAIR KIT
491		HW47070001 HW866BK-ENG0 HW47070001	HOWO WD615.47 ENGINE ASSEMBLY
492		VG1500119215 HW866BK-EMC0 VG1500119215	HOWO WD615 EXHOUST MANIFOLD CLAMP
493		WG9718710003 HW866BK-ELH0 WG9718710003	HOWO WD615 ELECTRICAL HORN
494		AZ1630840323 HW866BK-ELF0 AZ1630840323	HOWO WD615 ELECTRICAL LINE FOR FAN
495		VG1500010344 HW866BK-EL10	HOWO WD615 /STEYR 0015 ENGINE LINER
496		WG9719540021 HW866BK-EFT0 WG9719540021	HOWO WD615 EXHAUST FLEXIBLE TUBE




# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
497		WG9725710001 HW866BK-EBS0 WG9725710001	HOWO WD615 EXHAUST BRAKE SWITCH
498		VG1560030033/4 HW866BK-EB30	HOWO WD615 ENGINE CON ROD BEARING STD
499		VG1500010046 HW866BK-EB10 8150010046	HOWO WD615 ENGINE MAIN BEARING STD
500		WG9000360100 HW866BK-DRCD	HOWO WD615 DIAPHRAMGM CYL. LEFT
501		WG9000360101 HW866BK-DRCC	HOWO WD615 DIAPHRAMGM CYL. RIGHT
502		AZ9114160020 HW866BK-DDM0	HOWO WD615 DRIVEN DISC WITH MEMBERA 430mm
503		VG1560130080 HW866BK-DCA0 VG1560130080	HOWO SINO TRUCK WD615 DOUBLE CYL. AIR COMPRESSOR
504		WG1642440051 HW866BK-CTV0 WG1642440051/1	HOWO WD615 HIGH CONTROL VALVE (SCREWY SPRING)



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
505		WG9130583018 HW866BK-CTR0 WG9130583018	HOWO WD615 CONTACT RING
506		WG9725230042 HW866BK-CSV0	HOWO WD615 CLUTCH SERVO
507		WG911460030 HW866BK-CRG0 WG911460030	HOWO WD615 RELEASE BEARING
508		VG1500030023 HW866BK-CRB0	HOWO WD615 CON ROD BOLT
509		R61540080016 HW866BK-CRA1 R61540080016	HOWO TRUCK COMMON RAIL COMPONENT
510		R61514008016 HW866BK-CRA0 R61514008016	HOWO TRUCK COMMON RAIL
511		WG9000360523 HW866BK-CPV0	HOWO WD615 4-CIRCUIT PROTECTING VALVE
512		WG9114160011 HW866BK-CPPO WG9114160011	HOWO OM615 CLUTCH PRESSURE PLATE











# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
513		38254 HW866BK-CP13 191942-191942	HOWO WD615 CLUTCH DISK PLATE
514		WG1560161130 HW866BK-CP12 WG1560161130	HOWO WD615 CLUTCH DISK PLATE
515		WG1560161130 HW866BK-CP11 1861715035	HOWO WD615 CLUTCH DISK PLATE 420mm
516		WG9114160010 HW866BK-CP10	HOWO WD615 CLUTCH DISK PLATE 430mm
517		WG1642110002 HW866BK-COSD WG1642110002	HOWO WD615 OUTER SIDE COVER LEFT
518		WG1642110001 HW866BK-COSC WG1642110001	HOWO WD615 OUTER SIDE COVER RIGHT
519		WG9130583017 HW866BK-CNS0 WG9130583017	HOWO WD615 COMBINATION SWITCH
520		161500030009 HW866BK-CNR0 161500030009	HOWO WD615 CONNECTING ROD ASSY.



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
521		AZ9719580002 HW866BK-CNBC AZ9719580002	HOWO WD615 CONTROL BLOCK RIGHT
522		WG-9725230042/2 HW866BK-CMC1	HOWO OM615 CLUTCH CYLINDER
523		WG9719320105 HW866BK-CMC	HOWO OM615 CLUTCH MASTER CYLINDER
524		WG9925530022 HW866BK-CLP6 WG9925530022	HOWO WD615 CLAMP
525		AZ9719540018 HW866BK-CLP5 AZ9719540018	HOWO WD615 CLAMP
526		VG9103980060 HW866BK-CLP4 VG9103980060	HOWO WD615 CLAMP
527		VG9925530022 HW866BK-CLP3 VG9925530022	HOWO WD615 CLAMP
528		VG190003989300 HW866BK-CLP2 VG190003989300	HOWO WD615 CLAMP



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
529		VG1560110021 HW866BK-CLP1 VG1560110021	HOWO WD615 CLAMP
530		VG1560110226 HW866BK-CLP0 VG1560110226	HOWO WD615 CLAMP
531		WG9719230015 HW866BK-CHP0 WG9719230015	HOWO WD615 CLUTCH PUMP
532		WG972540053 HW866BK-CFT0 WG972540053	HOWO WD615 CORRUGATED FLEXIBLE METAL TUBE
533		190003989315 HW866BK-CCP1 190003989315	HOWO WD615 CIRCLIP
534		AZ9003980010 HW866BK-CCP0 AZ9003980010	HOWO WD615 CIRCLIP
535		2159333002 HW866BK-CCB0 2159333002	HOWO WD615 CLUTCH BODY
536		61500010383 HW866BK-CBK0 61500010383	HOWO WD615 CYL. BLOCK ASSY.



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
537		WG9100760065 HW866BK-BTY0 WG9100760065	HOWO WD615 BATTERY 165 AH
538		AZ9100440060 HW866BK-BSSI AZ9100440060	HOWO WD615 FRONT BRAKE SHOE SPRING
539		WG9100760100 HW866BK-BMS0	HOWO WD615 BATTERY MAIN SWITCH
540		WG9719582004 HW866BK-BLS0 WG9719582004	HOWO WD615 EMER BLINKER SYSTEM SWITCH
541		WG9200340068 HW866BK-BL10 WG9200340068	HOWO WD615 BRAKE LINING
542		AZ9100430218-11 HW866BK-BJLD AZ9100430218-11	HOWO WD615 BALL JOINT LEFT
543		AZ9100430218-4 HW866BK-BJLC AZ9100430218-4	HOWO WD615 BALL JOINT RIGHT
544		1880410038 HW866BK-BHPI	HOWO WD615 FRONT BRAKE SHOE PIN



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
545		190003311036 HW866BK-BDSJ 190003311036	HOWO WD615 BEARING OF DRIVING SHAFT (REAR,6212)
546		AZ9725521174 HW866BK-BCRB1 AZ9725521174	HOWO WD615 BOTTOM BRACE ROD C
547		AZ9631523175 HW866BK-BCRB AZ9631523175	HOWO WD615 BOTTOM BRACE ROD C
548		WG1642440060 HW866BK-BCR0 WG1642440060	HOWO WD615 BRACE ROD C
549		HW866BK-BCKJ	HOWO WD615 R-BRAKE CHAMBER REPAIR KIT
550		HW866BK-BCKI	HOWO WD615 F-BRAKE CHAMBER REPAIR KIT
551		150212K HW866BK-BBR2 150212K	HOWO WD615 BALL BEARING
552		635333050 HW866BK-BBR1 635333050	HOWO WD615 BALL BEARING



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
553		190003311416 HW866BK-BBR0 190003311416	HOWO WD615 BALL BEARING
554		VG1560090012 HW866BK-ATA1	HOWO WD615 ALTERNATOR ASSY. NEW MODEL
555		VG1560090010 HW866BK-ATA0	HOWO WD615 ALTERNATOR ASSY. OLD MODEL
556		WG9100710004 HW866BK-ASS0	HOWO WD615 AIR PRESSRUE SIGNAL SWITCH
557		HW866BK-ARK0	HOWO WD615 AIR REPAIR KIT
558		AZ1642440025 HW866BK-ARB0	HOWO WD615 AIR BAG (SHOCK ABSORBER)
559		WG9130713001 HW866BK-APS0 WG9130713001	HOWO WD615 AIR PRESSURE SENSOR
560		WG9719190008 HW866BK-AIH0	HOWO WD615 AIR INTAKE LINE HOSE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
561		WG9000270003 HW866BK-AHNL WG9000270003	HOWO WD615 LOW VOICE AIR HORN
562		WG9000270002 HW866BK-AHN0 WG9000270002	HOWO WD615 AIR HORN
563		WG9719190001 HW866BK-AFE0 WG9719190001	HOWO WD615 AIR FILTER
564		WG9725530250 HW866BK-AFC0 WG9725530250	HOWO WD615 AFTER COOLER
565		WG9000368471 HW866BK-AD00	HOWO WD615 AIR DRYER
566		31286070000 HW866BK-ACV0 31286070000	HOWO WD615 AIR CONTROL DISTRIBUTE VALVE
567		WG9725570001 HW866BK-ACL0	HOWO WD615 ACCELERATOR CABLE (dam truck)
568		HW866BK-ACK0	HOWO WD615 AIR COMPRESSOR REPAIR KIT



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
569		WG1500139000 HW866BK-ACC0 WG1500139000	HOWO WD615 AIR CONDITIONER COMPRESSOR (V-BELT TYPE)
570		HW866BK-ABK0	HOWO WD615 AIR BRAKE VALVE REPAIR KIT
571		HW866BK-4RK0	HOWO WD615 4-CIRCUIT PROTECTION VALVE REPAIR KIT
572		VG1560050041 HW709BK-EV1X0	HOWO D10 ENGINE VALVE EX.
573		HW19710	HOWO SINOTRUK GEARBOX
574		WG1664331061/1 HW058BK-WWS0	HOWO A7 WINDOW SWITCH
575		VG1246060042 HW058BK-WP02	HOWO WATER PUMP
576		VG1500060051 HW058BK-WP01	HOWO TRUCK WATER PUMP





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
577		VG1600060051 HW058BK-WP00	HOWO TRUCK WATER PUMP
578		199014320135 HW058BK-WHF0	HOWO TRUCK HOLLOW SHAFT
579		199012340123 HW058BK-WBTJ	HOWO A7 WHEEL BOLT REAR
580		WG9100410104 HW058BK-WBTI	HOWO WHEEL BOLT FRONT
581		WG9100410103 HW058BK-WBT1	HOWO WHEEL BOLT RAIL
582		HW058BK-WBT0	HOWO TRUCK BOLT & NUT
583		WG1642740010 HW058BK-WB20	HOWO WIPER ARM
584		WG1642740011 HW058BK-WB10	HOWO WIPER BLADE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
585		HW058BK-VCG0	HOWO TRUCK HEAD COVER GASKET
586		VG1246060082 HW058BK-VBT1 10PK1282	HOWO V-BELT
587		VG1246060091 HW058BK-VBT0 6PK1423	HOWO A7 BELT
588		AZ9925520268 HW058BK-UBT0	HOWO U BOLT with nut
589		VG1500090061 HW058BK-TSN0	HOWO WATER TEMPERATURE SENSOR
590		VG1246010036 HW058BK-THW1	HOWO A7 THRUST WASHER RAIL
591		VG1500010125 HW058BK-THW0	HOWO TRUCK THRUST WASHER
592		WG9719530307 HW058BK-TCH1	HOWO INTER COOLER AIR OUTLET HOSE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
593		WG9730530011 HW058BK-TCH0	HOWO TRUCK INTER COOLER HOSE
594		4102BZL-A21010 HW058BK-TCA0	HOWO TRUCK TURBO CHARGER
595		WG1642240030 HW058BK-STL0D	HOWO STEP LOWER LH
596		WG1642240031 HW058BK-STL0C	HOWO STEP LOWER RH
597		WG9925478228 HW058BK-STB0	HOWO STEERING BOX
598		VG1246090003 HW058BK-STA2	HOWO TRUCK STARTER MOTOR
599		VG1246090002 HW058BK-STA1	HOWO TRUCK STARTER
600		WG1560090001 HW058BK-STA0	HOWO TRUCK STARTER



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
601		AZ9130583119 HW058BK-SSC0	HOWO TRUCK STARTER SWITCH
602		WG2203040461 HW058BK-SR10	HOWO TRUCK SYNCHRONIZER RING
603		AZ9770591001 HW058BK-SPP0J	HOWO ENGINE SUPPORT REAR
604		WG2209280010 HW058BK-SMS0	HOWO SPEED OMEETER SENSOR
605		WG1642770099 HW058BK-SMR0	HOWO TRUCK SIDE MIRROR
606		AZ9100440005 HW058BK-SLRI	HOWO TRUCK SLACK ADJUSTER FRONT
607		WG9100440005-LH HW058BK-SLR0D	HOWO SLACK ADJUSTER LH
608		WG9100440005-RH HW058BK-SLR0C	HOWO SLACK ADJUSTER RH



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
609		WG2229100042 HW058BK-SLB0	HOWO SLIDING BLOCK
610		AZ9925470060 HW058BK-SGR0	HOWO TRUCK STEERING GEAR
611		PL420 HW058BK-SFEA VG1540080311	HOWO/ WEICHAIR TRUCK SEPARATE FILTER ASSEMBLY
612		VG1540080211 HW058BK-SFE2	HOWO TRUCK SEPARATE FILTER
613		PL420 HW058BK-SFE0 VG1540080311	HOWO/ WEICHAIR TRUCK SEPARATE FILTER WITH CUP
614		WG1642510007 HW058BK-SEA0	HOWO TRUCK SEAT ASSEMBLY
615		WG1642440082 HW058BK-SARJ2	HOWO TRUCK SHOCK ABSORBER REAR
616		AZ1664440069 HW058BK-SARJ0	HOWO TRUCK SHOCK ABSORBER REAR



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
617		AZ1664430103 HW058BK-SARI4	HOWO TRUCK SHOCK ABSORBER FRONT
618		WG1664430079 HW058BK-SARI3	HOWO A7 SHOCK ABSORBER FRONT
619		WG1642440081 HW058BK-SARI2	HOWO TRUCK SHOCK ABSORBER FRONT
620		WG1642430385 HW058BK-SARI1A	HOWO TRUCK SHOCK ABSORBER FRONT
621		WG1642430285 HW058BK-SARI1	HOWO TRUCK SHOCK ABSORBER FRONT
622		AZ1664430078 HW058BK-SARI0	HOWO TRUCK SHOCK ABSORBER FRONT
623		WG9725680014 HW058BK-SAR2	HOWO TRUCK SHOCK ABSORBER
624		AZ1608440016 HW058BK-SAR0 81437016629	HOWO TRUCK SHOCK ABSORBER



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
625		WG9925680028 HW058BK-SAC10	HOWO TRUCK SHOCK ABSORBER FOR CABIN FRONT
626		WG16029440091 HW058BK-SAC3	HOWO TRUCK SHOCK ABSORBER FOR CABIN
627		WG1642430283 HW058BK-SAC2	HOWO TRUCK SHOCK ABSORBER FOR CABIN FRONT
628	 <small>190X220X30 HW058BK-RWS2 3ring type</small>	190X220X30 HW058BK-RWS2 3 groove type	HOWO TRUCK REAR WHEEL SEAL 190X220X30 WITH O RING (3 groove type)
629	 <small>190X220X30 HW058BK-RWS1 2 rings type</small>	190X220X30 HW058BK-RWS1 2 groove type	HOWO TRUCK REAR WHEEL SEAL 190X220X30 WITH O RING (2 groove type)
630		AZ9112340113 HW058BK-RWS0	HOWO TRUCK REAR WHEEL SEAL 190*220*15 WITH O RING
631		32316 HW058BK-RLB4	HOWO TRUCK ROLLER BEARING
632		32310 HW058BK-RLB3	HOWO TRUCK ROLLER BEARING



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
633		32314 HW058BK-RLB2	HOWO TRUCK ROLLER BEARING
634		32311 HW058BK-RLB1	HOWO TRUCK ROLLER BEARING
635		WG9981032222 HW058BK-RLB0	HOWO TRUCK ROLLER BEARING
636		WG1664230086 HW058BK-RFD0D	HOWO TRUCK REAR FENDER LH
637		WG1664230085 HW058BK-RFD0C	HOWO TRUCK REAR FENDER RH
638		WG9719530270 HW058BK-RDT1	HOWO RADIATOR
639		WG9719530277 HW058BK-RDT0	HOWO RADIATOR
640		AZ9925525286 HW058BK-RBS0	HOWO TRUCK RUBBER SUPPORT





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
641		WG1664330003-LH HW058BK-R020	HOWO A7 WINDOW REGULATOR FL
642		WG1664330004-RH HW058BK-R010	HOWO A7 WINDOW REGULATOR FR
643		VG1540030005 HW058BK-PTR0	HOWO A7 PISTON RINGS
644		VG1540030004 HW058BK-PTN1	HOWO A7 PISTON
645		VG1246030015 HW058BK-PTN0	HOWO A7 PISTON
646		WG9731478037 HW058BK-PSP3	HOWO POWER STEERING PUMP
647		WG9725471216/1 HW058BK-PSP2	HOWO STEERING PUMP
648		WG9725471016 HW058BK-PSP1	HOWO POWER STEERING PUMP RAIL



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
649		14571220C HW058BK-PSP0	HOWO TRUCK POWER STEERING PUMP
650		HW058BK-PLT0	HOWO TRUCK RIM PLATE 7.00-20
651		WG9925478228 - ARM HW058BK-PIA0	HOWO TRUCK PITMAN ARM
652		AZ9631527175 HW058BK-PHR0UP	HOWO TRUCK PUSH ROD UPPER
653		AZ9631521174 HW058BK-PHR0L	HOWO TRUCK PUSH ROD LOWER
654		WG9231340317 HW058BK-OSR0	HOWO TRUCK OIL SEAL SEAT
655		17900360018  HW058BK-ORC0	HOWO OPERATING CYLINDER
656		WG2209280003 HW058BK-OPS0	HOWO PRESSURE SWITCH



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
657		WG2203240039 HW058BK-OP11	HOWO A7 OIL PUMP ASSY
658		WG2203240019 HW058BK-OP10	HOWO OIL PUMP ASSY
659		WG1540040022A HW058BK-OISJ	HOWO OIL SEAL REAR
660		VG1246070031 HW058BK-OFR1	HOWO TRUCK OIL FILTER
661		LF4054 HW058BK-OFR0 H18W01	HOWO/ MAN/ DAF/ DEUTZ/ IVECO/ BENZ/ RENAULT/ VOLVO/ STEYR TRUCK OIL FILTER
662		LF3444 HW058BK-OFE2 LF3444	HOWO TRUCK OIL FILTER
663		WG9925550002 HW058BK-OES0	HOWO A7 OIL LEVEL SENSOR
664		WG1664771010 - LH HW058BK-MR1D	HOWO MIRROR LH





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
665		WG1664771010 - RH HW058BK-MR1C	HOWO MIRROR RH
666		WG1642777010-LH HW058BK-MR0D	HOWO MIRROR LH
667		WG1642777020-RH  HW058BK-MR0C	HOWO MIRROR RH
668		WG1664771030 HW058BK-MR0A	HOWO A7 MIRROR ASSEMBLY
669		WG1664771030-1 HW058BK-MR01	HOWO A7 MIRROR
670		WG1664771040 HW058BK-MR00	HOWO A7 MIRROR
671		WG9727540001 HW058BK-MFRA0	HOWO TRUCK MUFFLER ASSEMBLY
672		WG9725520286 HW058BK-LSGAB TYPE 2	HOWO TRUCK LEAF SPRING REAR assy 25*90 - Type 2 總成 反槽



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
673		WG9725520286 HW058BK-LSGA TYPE 1	HOWO TRUCK LEAF SPRING REAR assy 25*90 - Type 1 總成正槽
674		WG9731520041 HW058BK-LSG1B	HOWO TRUCK LEAF SPRING FRONT ; 3rd PC 14*90
675		WG9731520041 HW058BK-LSG1A 2nd PC	HOWO TRUCK LEAF SPRING FRONT ; 2nd PC 14*90
676		WG9731520041 HW058BK-LSG1 1st PC	HOWO TRUCK LEAF SPRING FRONT ; 1st PC 14*90
677		WG9725520286+003 HW058BK-LSG0-003	HOWO TRUCK LEAF SPRING REAR ; 3rd PC 25*90
678		WG9725520286+002 HW058BK-LSG0-002	HOWO TRUCK LEAF SPRING REAR ; 2nd PC 25*90
679		WG9725520286+001 HW058BK-LSG0	HOWO TRUCK LEAF SPRING REAR ; 1st PC 25*90
680		WG1664110006 HW058BK-LGO1	HOWO A7 LOGO



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
681		AZ1646950001 HW058BK-LG00	HOWO TRUCK LOGO
682		WG9700240022 HW058BK-KGS1	HOWO SHIFT KNOB
683		WG9925240020 HW058BK-KGS0	HOWO TRUCK GEARBOX SHIFT KNOB
684		WG9918530002/2 HW058BK-ITC0	HOWO A7 INTER COOLER
685		HW058BK-IJS0	HOWO A7 INJECTOR SLEEVE
686		WG9725190919 HW058BK-IAP2	HOWO INLET AIR PIPE
687		WG9725190008 with clamp HW058BK-IAP1C	HOWO TRUCK INLET AIR PIPE with clamp
688		WG9725190008 HW058BK-IAP1	HOWO TRUCK INLET AIR PIPE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
689		WG9925191003 HW058BK-IAP0	HOWO A7 INLET AIR PIPE
690		AZ9925720001 HW058BK-HLTD	HOWO A7 HEAD LAMP BRACKET LH
691		AZ9925720002 HW058BK-HLTC	HOWO A7 HEAD LAMP BRACKET RH
692		VG9719720001 HW058BK-HLPD0	HOWO TRUCK HEAD LAMP LH
693		VG9719720002 HW058BK-HLPC0	HOWO TRUCK HEAD LAMP RH
694		WG9925720001 HW058BK-HLP1D	HOWO A7 HEAD LAMP LH
695		WG9925720002 HW058BK-HLP1C	HOWO A7 HEAD LAMP RH
696		WG9719720025 HW058BK-HLP0D	HOWO TRUCK HEAD LAMP LH



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
697		WG9719720026 HW058BK-HLP0C	HOWO TRUCK HEAD LAMP RH
698		WG1664340002 HW058BK-HDLA	HOWO TRUCK HANDLE ASSEMBLY
699		WG9719820004 HW058BK-HDC1	HOWO CAB LIFT HYD. CYLINDER
700		WG9925824014 HW058BK-HDC0	HOWO TRUCK LIFTING HYD. CYLINDER
701		HW058BK-GT41	HOWO WD615 GASKET FULL SET
702		HW058BK-GT40	HOWO A7 GASKET FULL SET
703		VG1500040065 HW058BK-GT31	HOWO TRUCK CYL HEAD GASKET
704		6126000403 HW058BK-GT30	HOWO TRUCK CYL HEAD GASKET





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
705		VG1246150016 HW058BK-GT21	HOWO TRUCK OIL PAN GASKET
706		VG14150004 HW058BK-GT20	HOWO TRUCK OIL PAN GASKET
707		WG9725240204-1 HW058BK-GSC0	HOWO ROD END FOR GEAR SHIFT CABLE
708		VG1095020238  HW058BK-G100	HOWO TRUCK RING GEAR FOR FLYWHEEL
709		AZ1540020204R HW058BK-FWA0	HOWO TRUCK FLYWHEEL ASSEMBLY
710		WG1642241031 HW058BK-FTP0D	HOWO 2010 series FOOT STEP LH
711		WG1642241032 HW058BK-FTP0C	HOWO 2010 series FOOT STEP RH
712		095420-0260 HW058BK-FPV0	HOWO FUEL PRESSURE CONTROL VALVE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
713		WG1642111011 HW058BK-FPN0	HOWO TRUCK FRONT PANEL COVER
714		0 440 008 080 HW058BK-FP10	HOWO TRUCK FUEL PUMP
715		179000320013 HW058BK-FLN0	HOWO TRUCK FLANGE NUT
716		AZ1642110001 HW058BK-FGR0	HOWO TRUCK FRONT GRILLE
717		VG1500080100 HW058BK-FFP0	HOWO TRUCK FUEL FEED PUMP
718		VG1540080110 HW058BK-FFE2	HOWO WD615 FUEL FILTER
719		WG9925550182 HW058BK-FFE1 FS36277	HOWO SEPARATED FILTER ASSEMBLY
720		WK962/7 HW058BK-FFE0 8193841	HOWO/ MAN/ VOLVO TRUCK FUEL FILTER



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
721		WG1664230017 HW058BK-FFD0D	HOWO TRUCK FRONT FENDER LH
722		WG1664230016 HW058BK-FFD0C	HOWO TRUCK FRONT FENDER RH
723		WG1642241021/3 HW058BK-FBU0	HOWO TRUCK FRONT BUMPER
724		WG9725540153 HW058BK-EXP0	HOWO EXHAUST PIPE
725		VG1560040037 HW058BK-EV3X1	HOWO 371 ENGINE VALVE SEAT EX.
726		VG1246040013 HW058BK-EV3X	HOWO TRUCK ENGINE VALVE SEAT EX.
727		VG1560040057 HW058BK-EV3W1	HOWO 371 ENGINE VALVE SEAT IN.
728		VG1246040012 HW058BK-EV3W	HOWO TRUCK ENGINE VALVE SEAT IN.



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
729		VG1246040014 HW058BK-EV20	HOWO A7 380 ENGINE VALVE GUIDE
730		VG1246050021 HW058BK-EV1X	HOWO A7 380 ENGINE VALVE EX.
731		VG1560051041 HW058BK-EV1W1	HOWO A7 ENGINE VALVE IN.
732		VG1246050022 HW058BK-EV1W	HOWO A7 380 ENGINE VALVE IN.
733		VG1246060030-1 HW058BK-ENFA1	HOWO ENGINE FAN ASSEMBLY
734		VG1246060051-1 HW058BK-ENFA0	HOWO D12 ENGINE FAN ASSEMBLY
735		VG1246060030 HW058BK-ENF1	HOWO SILICONE FAN
736		VG1246060051 HW058BK-ENF0	HOWO D12 SILICONE FAN





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
737	 <b>OE NO: HOWO 08</b> <b>MODEL: HOWO</b>	HOWO 08 HW058BK-EMT1	HOWO TRUCK 08 ENGINE MOUNTING
738	 <b>OE NO:ZAZ9725520273</b> <b>MODEL: HOWO</b>	ZAZ9725520273 HW058BK-EMT0	HOWO TRUCK 08 ENGINE MOUNTING
739		VG1246010028 HW058BK-EL10	HOWO A7 ENGINE LINER
740		WG9725540199 HW058BK-EFT0	HOWO EXHAUST FLEXIBLE TUBE ASSEMBLY
741		VG1246030011/12 HW058BK-EB31	HOWO TRUCK ENGINE CON ROD BEARING STD
742		VG1246010011/12 HW058BK-EB30	HOWO A7 CON ROD BEARING STD
743		VG1246010034/35 HW058BK-EB20A VG1246010034/36	HOWO A7 ENGINE MAIN BEARING 0.10
744		VG1246010034/15 HW058BK-EB11	HOWO ENGINE MAIN BEARING STD



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
745		VG1246010034/35 HW058BK-EB10 VG1246010034/36	HOWO A7 ENGINE MAIN BEARING STD
746		AZ9914310126 HW058BK-DRS0	HOWO DRIVE SHAFT
747		WG9014320076 HW058BK-DRA0	HOWO TRUCK DIFFERENTIAL ROCKER ARM
748		WG1642341001 HW058BK-DLK0	HOWO TRUCK DOOR LOCK ASSEMBLY
749		AZ9981320137 HW058BK-DFF3	HOWO DIFFERENTIAL
750		AZ9231320271+001 HW058BK-DFF2	HOWO DIFFERENTIAL ASSEMBLY
751		AZ99014320271 HW058BK-DFF1	HOWO DIFFERENTIAL ASSEMBLY
752		AZ9981320136 HW058BK-DFF0	HOWO DIFFERENTIAL ASSEMBLY



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
753		WG9725160510 HW058BK-CRG1	HOWO CLUTCH RELEASE BEARING
754		315100034 HW058BK-CRG0	HOWO CLUTCH RELEASE BEARING
755		AZ9921160200 HW058BK-CPP0	HOWO TRUCK CLUTCH PRESSURE PLATE
756		VG1246050001 HW058BK-CMT0	HOWO A7 CAMSHAFT
757		61560040040A HW058BK-CLH0	HOWO TRUCK CYLINDER HEAD
758		AZ1246020013 HW058BK-CKS0	HOWO A7 CRANKSHAFT
759		AZ9319313260 HW058BK-CBA0	HOWO TRUCK CENTER BEARING
760		WG9000360520/2 HW058BK-BVE1	HOWO TRUCK BRAKE VALVE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
761		WG9925540003-1 HW058BK-BVE0B	HOWO BUTTERFLY VALVE
762		WG9925540003 HW058BK-BVE0	HOWO TRUCK BRAKE VALVE
763		AZ9232520010 HW058BK-BRKH0	HOWO SPRING BRACKET REAR LH
764		AZ9232520011 HW058BK-BRKG0	HOWO SPRING BRACKET REAR RH
765		WG9725520277 HW058BK-BRKD	HOWO TRUCK SPRING BRACKET LH
766		Wg9725520279 HW058BK-BRKC	HOWO TRUCK SPRING BRACKET RH
767		WG9000360600  HW058BK-BKC1	HOWO TRUCK BRAKE CHAMBER
768		WG9000360601 HW058BK-BKC0	HOWO TRUCK BRAKE CHAMBER





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
769		WG9100443050 HW058BK-BDP0	HOWO TRUCK BRAKE PAD
770		WG9231342006 HW058BK-BDM0	HOWO TRUCK BRAKE DRUM
771		AZ9725529213 HW058BK-B331	HOWO TRUCK TORQUE ROD BUSH RAIL
772		AZ9631521177 HW058BK-B330	HOWO TRUCK TORQUE ROD BUSH 85*57
773		VG1246030010 HW058BK-B030	HOWO A7 CON ROD BUSH
774		WG1095094002  HW058BK-ATA0	HOWO TRUCK ALTERNATOR ASSY.
775		WG9925190006 HW058BK-ARH0	HOWO A7 AIR HOSE
776		AZ9719413003 HW058BK-AMS0D	HOWO TIE ROD ARM LH



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
777		AZ9719413004 HW058BK-AMS0C	HOWO TIE ROD ARM RH
778		WG9725190102 + WG9725190103 HW058BK-AFR0	HOWO TRUCK AIR FILTER
779		WG9000360521 HW058BK-AD00	HOWO AIR DRYER
780		VG1246130008 HW058BK-ACS1	HOWO TRUCK AIR COMPRESSOR
781		VG1246130008 HW058BK-ACS0	HOWO TRUCK AIR COMPRESSOR
782		GASKET 8	HOWO GASKET 8
783		DZ9114160044	HOWO CLUTCH RELEASE BEARING
784		DZ9114160032	HOWO CLUTCH DISC 430mm



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
785		CY4102B2L	HOWO LINER SET
786		AZ9981340070	HOWO PLANETARY CARRIER ASSEMBLY
787		AZ9981340063 AZ9981340063	HOWO BRAKE PLATE BOTTOM RH
788		AZ9981340062	HOWO BRAKE PLATE BOTTOM LH
789		AZ9981320201	HOWO HALF SHAFT GEAR WASHER
790		AZ9925540080	HOWO A7 MUFFLER ASSEMBLY
791		AZ99100550031	HOWO FUEL TANK CAP
792		AZ9725951011 AZ9725951011	HOWO BRACKET RIGHT



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
793		AZ9725951010 AZ9725951010	HOWO BRACKET LEFT
794		AZ9725591020	HOWO A7 ENGINE FRONT RUBBER SUPPORT
795		AZ9725538055	HOWO SHROUD COVER
796		AZ9725529272-3	HOWO WD615 V-BRACE ROD TOQUE ROD REPAIR KIT
797		AZ9725430010	HOWO STEERING STRAIGHT LINK
798		AZ9725360020	HOWO COMBINATION BRAKET
799		AZ9725160390	HOWO CLUTCH PLATE
800		AZ9725160200	HOWO CLUTCH PLATE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
801		AZ9725160100	HOWO CLUTCH PLATE
802		AZ9725160065	HOWO CLUTCH SEPARATION RING
803		AZ9725160010	HOWO CLUTCH PLATE
804		AZ9719410041	HOWO STEERING TIE ROD ARM (LEFT)
805		AZ9719410040	HOWO STEERING TIE ROD ARM (RIGHT)
806		AZ9719199015	HOWO A7 RUBBER HOSE
807		AZ9700430050-1	Tie rod assembly( $\phi$ 50);spare parts for truck;SINOTRUK HOWO;Tie Rod 4*2(290)
808		AZ9700290150	HOWO QH50 WG50 PTO



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
809		AZ9631521175	HOWO PUSH ROD
810		AZ9231320745 AZ9231320745	HOWO MIDDLE AXLE DRIVE
811		AZ9231320704	HOWO REAR AXEL MIDDLE PART
812		AZ9231320273	HOWO DIFFERENTIAL ASSEMBLY
813		AZ9231320264	HOWO AXLE BOX COVER
814		AZ9231320205	HOWO OUTLET FLANGE
815		AZ9231320154	HOWO AXLE GEAR PAD
816		AZ9231320096	HOWO SINOTRUK REAR AXLE GEAR GASKET



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
817		AZ9231320091	HOWO HALF AXLE GEAR GASKET
818		AZ9128320015	HOWO GEAR FLANGE
819		AZ9123360070	HOWO Hand brake valve
820		AZ9114160010	HOWO CLUTCH COVER
821		AZ9112550213	HOWO FUEL TANK CAP
822		AZ9100760102	HOWO BATTERY CASE TOP
823		AZ9100583058 AZ9100583058	HOWO SPEEDOMETER SENSOR (BIG) - SIEMENS
824		AZ9100440030	HOWO FRONT BRAKE SHOE ASSEMBLY



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
825		AZ9100430218-002	HOWO BALL JOINT RIGHT
826		AZ9100430218-001/2	HOWO BALL JOINT SET
827		AZ9100430218-001	HOWO BALL JOINT LEFT
828		AZ9100430021-002	HOWO BALL JOINT
829		AZ9100430021-001	HOWO BALL JOINT
830		AZ9100413045	HOWO KING PIN SET
831		AZ91004130045-XLB	HOWO STEERING PIN SET
832		AZ9100410061	HOWO FRONT WHEEL OIL SEAL





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
833		AZ2214060015	HOWO RESSORT DEFREIN D'EMBAYAGE D
834		AZ2214060010	HOWO RESORT DEFREIN EMBALLAGE G
835		AZ2210100126	HOWO GEAR HUB
836		AZ2210100124	HOWO GEAR BOX SLIDING SLEEVE
837		AZ2210040709 AZ2210040709	HOWO GEAR HUB SET
838		AZ2210040012	HOWO SPLINED GEAR PAD
839		AZ2210020572 AZ2210020572	HOWO FORTY-FIVE FILES CONE RING
840		AZ2210020502 AZ2210020502	HOWO THIRD & FORTH GEAR CONE RING



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
841		AZ2203040009	HOWO GEAR BOX MAIN SHAFT WITH BALL HEAD
842		AZ2201000002+002	HOWO POWER TAKE OFF
843		AZ1880410031-XLB	HOWO STEERING PIN SET
844		AZ1880410031	HOWO STEERING PIN
845		AZ1664430095	HOWO CABIN BUSHING
846		AZ1664430094	HOWO A7 FRONT SUSPENSION LOWER STOP BLOCK
847		AZ164244021	HOWO SHOCK ABSORBER
848		AZ1642430256	HOWO BUSHING





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
849		AZ1642430231	HOWO FRONT SUPPORT LH
850		AZ1642430219	HOWO A7 CABIN ROTATING SHAFTASSEMBLY
851		AZ1642430091 AZ1642430091	HOWO FRONT SHOCK ABSORBER
852		AZ1642430081	SINOTRUK HOWO CABIN DAMPER
853		AZ1642430061	HOWO RUBBER BUSH
854		AZ1500060050	HOWO WATER PUMP
855		A5A	HOWO FUSE
856		A30A	HOWO FUSE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
857		A25A	HOWO FUSE
858		A20A	HOWO FUSE
859		A10A	HOWO FUSE
860		991100680052 991100680052	HOWO A7 / SHACKMAN FRONT STABILIZER ROD BUSHING
861		WG9725520278 9725520278	HOWO RUBBER DAMPER
862		9725310020	HOWO UNIVERSAL JOINT
863		9114160030 9114160030 9114160030	HOWO CLUTCH RELEASE BEARING
864		8PK1080	HOWO V-BELT



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
865		850x20x14	WHEEL RIM 850x20x14 for HOWO TRUCK 10 holes (LOCK RING TYPE)
866		825x22.5x14	WHEEL RIM 825x22.5x14 for HOWO TRUCK 10 holes
867		752W06101-0003	SINOTRUK HOWO T5G SITRAK C7H COOLANT PUSH IN CONNECTOR
868		735320499 735320499	HOWO 3G NEEDLE CAGE
869		735320401 735320401	HOWO 1G. NEEDLE CAGE
870		734310110	HOWO OIL SEAL
871		72900240028	HOWO BUMPER
872		68x166	HOWO UNIVERSAL JOINT



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
873		61560080219	HOWO FLEXIBLE DRIVE PLATE
874		615600300 615600300	HOWO PISTON RING (61560030047+ 61560030048 + 61560030045)
875		61557010008 61557010008	HOWO GEAR CASE
876		61500090051 61500090051	HOWO OIL PRESSURE SENSOR
877		61500090029 61500090029	HOWO STARTER
878		61500040040 61500040040	HOWO CYLINDER HEAD
879		61500010334 61500010334	HOWO OIL RADIATOR
880		61500010012 61500010012	HOWO FLYWHEEL HOUSING



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
881		614050119 614050119	HOWO ROCKER ARM SUPPORT
882		614050049 614050049	HOWO ROCKER ARM
883		614010083B 614010083B	HOWO COVER
884		612600040099	HOWO INJECTOR SLEEVE
885		6100060051B	HOWO TRUCK WATER BLOCK
886		570304002	HOWO ROLLER BEARING
887		5623051110	HOWO HYDRAULIC LIMIT VALVE
888		480A470748A	HOWO FILTER



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
889		480A470748	HOWO FILTER
890		412Q-18D1.20.10	HOWO AIR COMPRESOR
891		4046025	HOWO TURBO CHARGER
892		32314X3A	HOWO ROLLER BEARING
893		32311X2A	HOWO WHEEL TAPER ROLLER BEARING
894		26013314080	HOWO UNIVERSAL JOINT
895		26013314062 26013314062	HOWO 165 PLANE FLANGE
896		2159304013	HOWO ROLLER BEARING





# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
897		2159232001 2159232001	HOWO OUTPUT SHAFT
898		202V15201-6227	HOWO EXHAUST MANIFOLD
899		199112340029-RK	HOWO PLANETARY CARRIER repair kit
900		199112340029	HOWO PLANETARY CARRIER
901		199100680037	HOWO REAR STABILIZER BEARING
902		199014320144 199014320144	HOWO COVER
903		199014320061 199014320061	HOWO WASHER FOR DIFFERENTIAL HOUSING FRICTION DISC
904		199012340019 199012340019	HOWO SPACER RING




# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
905		199012340005 199012340005	HOWO HELICAL GEAR
906		199012340004 199012340004	HOWO BOLT
907		19036311080	HOWO UNIVERSAL JOINT
908		189000340068	HOWO RIVET
909		1880680024	SINOTRUCK HOWO FIX BLOCK
910		1780680035	HOWO RUBBER BUSH
911		178000680035	HOWO REAR STABILIZER BUSHING
912		14750667	HOWO HAND OPERATING VALVE



# BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.  
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

## HOWO CATALOGUE

Date: 2022/08/25

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
913		129.81.90685.0336	HOWO WHEEL END COVER
914		1269338095 1269338095	HOWO SPEEDOMETER COVER
915		11203+996914	HOWO RELEASE BEARING
916		090310-0280	RELIEF VALVE FOR HOWO TRUCK
917		0735370011 0735370011	HOWO BALL BEARING SKF
918		0732040385	HOWO PRING