



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
1		471Q-1007006 ZYD08BVLC0 471Q-1007006	ZYOTE 2008 VALVE CLAMP
2		3782010-02 ZYD08BK-WWSJ0 3782010-02	ZYOTE 2008 OUTER REAR VIEW MIRRORWINDOW SWITCH
3		6311013-02 ZYD08BK-WTH6 6311013-02	ZYOTE 2008 NO.6 WATER HOSE
4		6311012-02 ZYD08BK-WTH5 6311012-02	ZYOTE 2008 NO.5 WATER HOSE
5		6311011-02 ZYD08BK-WTH3 6311011-02	ZYOTE 2008 NO.3 WATER HOSE
6		5207013-02 ZYD08BK-WTH1 5207013-02	ZYOTE 2008 NO.1 WATER HOSE
7		476Q-6L-1000022 ZYD08BK-WTH0 476Q-6L-1000022	ZYOTE 2008 WATER HOSE
8		6307011-02 ZYD08BK-WSTTD 6307011-02	ZYOTE 2008 AROUND TAIL DOOR WEATHER STRIP



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
9		471Q-1000044 ZYD08BK-WSHOC 471Q-1000044	ZYOTE 2008 OIL COLLECTOR WASHER
10		3101011-02 ZYD08BK-WRM0 3101011-02	ZYOTE 2008 (15-6JJ) WHEEL RIM
11		3741030-02 ZYD08BK-WPSJ 3741030-02	ZYOTE 2008 SWITCH OF REAR FOG WASHER
12		6311010-02 ZYD08BK-WPNJ 6311010-02	ZYOTE 2008 WIPER NOZZLE ASSEMBLY REAR
13		5207020-02 ZYD08BK-WPNI 5207020-02	ZYOTE 2008 FRONT WIPER NOZZLE
14		6310012-02 ZYD08BK-WPBJ 6310012-02	ZYOTE 2008 WIPER BRUSH REAR
15		471Q-1307950-A ZYD08BK-WP00 471Q-1307950-A	ZYOTE 2008 WATER PUMP
16		6203020-02 ZYD08BK-WNGJD 6203020-02	ZYOTE 2008 REAR DOOR GLASS LH



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
17		6203025-02 ZYD08BK-WNGJC 6203025-02	ZYOTE 2008 REAR DOOR GLASS RH
18		5403015-02 ZYD08BK-WNGDT2 5403015-02	ZYOTE 2008 WINDOW REAR TRIANGLE GLASS LH
19		6403020-02 ZYD08BK-WNGD1 6403020-02	ZYOTE 2008 GLASS FRONT LEFT DOOR
20		6403025-02 ZYD08BK-WNGC1 6403025-02	ZYOTE 2008 GLASS FRONT RIGHT DOOR
21		5206014-02 ZYD08BK-WIS0 5206014-02	ZYOTE 2008 WINDSHIELD SEALING FRAME
22		6303016-02 ZYD08BK-WINJ0 6303016-02	ZYOTE 2008 WINDSHIELD TAIL DOOR
23		5206011-02 ZYD08BK-WINI0 5206011-02	ZYOTE 2008 WINDSHIELD FRONT
24		8403101-02 ZYD08BK-WIGD 8403101-02	ZYOTE 2008 FRONT WING LH



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
25		8403102-02 ZYD08BK-WIGC 8403102-02	ZYOTE 2008 FRONT WING RH
26		471Q-2-1000020 ZYD08BK-WIC0 471Q-2-1000020	ZYOTE 2008 TIE-IN, WATER INLET
27		8403038-02 ZYD08BK-WIB0 8403038-02	ZYOTE 2008 FRONT WING 2 INFLATE SCREW
28		38410-66113 ZYD08BK-WHP0 38410-66113	ZYOTE 2008 WASH PUMP
29		6203011-02 ZYD08BK-WGSJ 6203011-02	ZYOTE 2008 WINDOW GLASS SEAL REAR DOOR
30		5403018-02 ZYD08BK-WGSDT2 5403018-02	ZYOTE 2008 REAR LEFT TRIANGLE GLASS RUBBER BAR
31		5403022-02 ZYD08BK-WGSCT2 5403022-02	ZYOTE 2008 REAR RIGHT TRIANGLE GLASS RUBBER BAR
32		6403011-02 ZYD08BK-WGS1 6403011-02	ZYOTE 2008 FRONT DOOR GLASS SEAL BAR



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
33		6303019-02 ZYD08BK-WFBTD 6303019-02	ZYOTE 2008 WATERPROOF BAR TAIL DOOR
34		6207012-02 ZYD08BK-WFBJ 6207012-02	ZYOTE 2008 WATERPROOF BAR REAR DOOR
35		6407011-02 ZYD08BK-WFBI 6407011-02	ZYOTE 2008 WATERPROOF BAR FRONT DOOR
36		3741020-02 ZYD08BK-WB3J0 3741020-02	ZYOTE 2008 WIPER MOTOR REAR
37		3741010-02 ZYD08BK-WB3I0 3741010-02	ZYOTE 2008 WIPER MOTOR FRONT
38		6310011-02 ZYD08BK-WB2J0 6310011-02	ZYOTE 2008 WIPER ARM REAR
39		5205021-03 ZYD08BK-WB2ID6 5205021-03	ZYOTE 2008 FRONT WIPER ARM LH (1.6L)
40		5205021-03B ZYD08BK-WB2ID3 5205021-03B	ZYOTE 2008 FRONT WIPER ARM LH (1.3L)



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
41		5205011-03 ZYD08BK-WB2IC6 5205011-03	ZYOTE 2008 FRONT WIPER ARM RH (1.6L)
42		5205011-03B ZYD08BK-WB2IC3 5205011-03B	ZYOTE 2008 FRONT WIPER ARM RH (1.3L)
43		5205030-02 ZYD08BK-WB26 5205030-02	ZYOTE 2008 WIPER ARM (1.6L)
44		5205030-03B ZYD08BK-WB23 5205030-03B	ZYOTE 2008 WIPER ARM (1.3L)
45		5205031-02 ZYD08BK-WACI 5205031-02	ZYOTE 2008 WIPER ARM CAP FRONT
46		1104316-02 ZYD08BK-VTH5 1104316-02	ZYOTE 2008 VENTILATE HOSE No. 5
47		1104314-02 ZYD08BK-VTH4 1104314-02	ZYOTE 2008 VENTILATE HOSE No. 4
48		1104313-02 ZYD08BK-VTH3 1104313-02	ZYOTE 2008 VENTILATE HOSE No. 3



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
49		1104312-02 ZYD08BK-VTH2 1104312-02	ZYOTE 2008 VENTILATE HOSE No. 2
50		1104311-02 ZYD08BK-VTH1 1104311-02	ZYOTE 2008 VENTILATE HOSE No. 1
51		471Q-1007005 ZYD08BK-VSPR0 471Q-1007005	ZYOTE 2008 VALVE SPRING RETAINER RING 1.3 - 1.6 L
52		471Q-1007004 ZYD08BK-VSPA 471Q-1007004	ZYOTE 2008 VALVE SPRING RETAINER
53		471Q-1007003 ZYD08BK-VSP0 471Q-1007003	ZYOTE 2008 VALVE SPRING
54		471Q-1-1000092 ZYD08BK-VPV0 471Q-1-1000092	ZYOTE 2008 VACUUM PIPE VALVE
55		471Q-1014006 ZYD08BK-VCG0 471Q-1014006	ZYOTE 2008 VALVE ROCKER ARM CHAMBER COVER GASKET
56		471Q-1000027 ZYD08BK-VBT0 471Q-1000027	ZYOTE 2008 V-BELT FOR GENERATOR



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
57		471Q-1007806 ZYD08BK-VASX 471Q-1007806	ZYOTE 2008 VALVE SEAL EX.
58		471Q-1007807 ZYD08BK-VASW 471Q-1007807	ZYOTE 2008 VALVE SEAL IN.
59		1104030-02 ZYD08BK-UTVFP 1104030-02	ZYOTE 2008 UNILATERALISM VALVE FOR FUEL FILLING PIPE
60		6206200-02 ZYD08BK-UHNJD 6206200-02	ZYOTE 2008 LH DOOR UPPER HINGE REAR
61		6206100-02 ZYD08BK-UHNJC 6206100-02	ZYOTE 2008 RH DOOR UPPER HINGE REAR
62		476Q-3L-1100800 ZYD08BK-TSN1 476Q-3L-1100800	ZYOTE 2008 INTAKE AIR TEMPERATURE PRESSURE SENSOR 1.3 - 1.6
63		471Q-1L-1300800-B ZYD08BK-TSN0 471Q-1L-1300800-B	ZYOTE 2008 WATER TEMPERATURE SENSOR
64		471Q-1000809 ZYD08BK-TSBPA 471Q-1000809	ZYOTE 2008 CRANKSHAFT BELT PULLEY ASSY



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
65		471Q-1000806 ZYD08BK-TSBP0 471Q-1000806	ZYOTE 2008 TENSIONER BEARING PULLEY
66		3101110-02 ZYD08BK-TRC1 3101110-02	ZYOTE 2008 TRIM CAP FOR RIM SECTION (SMALL)
67		2803022-02 ZYD08BK-TRC0 2803022-02	ZYOTE 2008 TRIM CAP FOR FRONT BUMPER RIGHT HOOK
68		476Q-6L-1300001 ZYD08BK-TMSCP 476Q-6L-1300001	ZYOTE 2008 THERMOSTAT RIND ASSY
69		471Q-1306950 ZYD08BK-TMS0 471Q-1306950	ZYOTE 2008 THERMOSTAT
70		471Q-1300803 ZYD08BK-TMRW 471Q-1300803	ZYOTE 2008 WATER THERMOMETER
71		1209110-02 ZYD08BK-TLPX 1209110-02	ZYOTE 2008 TAIL PIPE EX.
72		1607117-02 ZYD08BK-TLC0 1607117-02	ZYOTE 2008 TRAIGHT COUPLING



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
73		476Q-6L-1107950-B ZYD08BK-THLA 476Q-6L-1107950-B	ZYOTE 2008 THROTTLE ASSY
74		471Q-1000017 ZYD08BK-TBS0 471Q-1000017	ZYOTE 2008 TENSIONER BEARING SPRING
75		471Q-1000026 ZYD08BK-TBP0 471Q-1000026	ZYOTE 2008 WATER PUMP BELT PULLEY
76		476Q-6L-1000800 ZYD08BK-TBEA 476Q-6L-1000800	ZYOTE 2008 TIMING BELT FRONT RIGHT CAPO ASSY
77		471Q-1000016 ZYD08BK-TBE0 471Q-1000016	ZYOTE 2008 TIMING BELT
78		2906112-02 ZYD08BK-SZS0 2906112-02	ZYOTE 2008 STABILIZER SLEEVE
79		2916200-02 ZYD08BK-SZR0 2916200-02	ZYOTE 2008 TRANSY STABILIZER ROD
80		2906113-02 ZYD08BK-SZB0 2906113-02	ZYOTE 2008 STABILIZER BRACKET



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
81		5207010-02 ZYD08BK-SYP0 5207010-02	ZYOTE 2008 SPRAYER POT
82		3402010-02 ZYD08BK-SWH0A 3402010-02	ZYOTE 2008 STEERING WHEEL FRAME (STANDARD)
83		3748010-02 ZYD08BK-SWCJ0 3748010-02	ZYOTE 2008 SWITCH OF REAR DEFROSTER
84		3404100-02 ZYD08BK-SU80 3404100-02	ZYOTE 2008 STEERING GEAR UPPER SHAFT
85		2904115-02 ZYD08BK-SU7L 2904115-02	ZYOTE 2008 LOWER SUSPENSION ARM ASSY, LEFT
86		2904120-02 ZYD08BK-SU7C 2904120-02	ZYOTE 2008 LOWER SUSPENSION ARM ASSY. RIGHT
87		2906111-02 ZYD08BK-STZ0 2906111-02	ZYOTE 2008 STABLIZER
88		6209010-02 ZYD08BK-STPJDD 6209010-02	ZYOTE 2008 REAR LH DOOR STOPPER ASSY



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
89		6209020-02 ZYD08BK-STPJCD 6209020-02	ZYOTE 2008 REAR RH DOOR STOPPER ASSY
90		6408010-02 ZYD08BK-STPIDD 6408010-02	ZYOTE 2008 ZYOTE 2008 FRONT LH DOOR STOPPER ASSY
91		6408020-02 ZYD08BK-STPICD 6408020-02	ZYOTE 2008 ZYOTE 2008 FRONT RH DOOR STOPPER ASSY
92		6309015-02 ZYD08BK-STP0TD 6309015-02	ZYOTE 2008 TAIL DOOR STOPPER ASSY
93		3406010-02 ZYD08BK-STH0 3406010-02	ZYOTE 2008 STEERING PUMP OIL INLET HIGH PRESSURE PIPE
94		471Q-3708950 ZYD08BK-STA0 471Q-3708950	ZYOTE 2008 STARTER ASSY 1.3-1.6L
95		3774021-02 ZYD08BK-SSH0UP 3774021-02	ZYOTE 2008 UPPER SHAFT , STEERING SHAFT
96		3404200-02 ZYD08BK-SSH0LW 3404200-02	ZYOTE 2008 LOWER SHAFT , STEERING LOWER SHAFT



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
97		2911024-02 ZYD08BK-SRS1 2911024-02	ZYOTE 2008 LOWER SEAT, COIL SPRING--REAR SUSPENSION FRAME ASSY
98		2911021-02 ZYD08BK-SRS0 2911021-02	ZYOTE 2008 UPPER COILED SPRING SEAT FOR REAR SUSPENSION FRAME ASSY
99		471Q-3707800 ZYD08BK-SPL0 471Q-3707800	ZYOTE 2008 SPARK PLUG
100		2810100A02 ZYD08BK-SPFW 2810100A02	ZYOTE 2008 VEHICLE SUBSIDIARY FRAME WELDING ASSY 1.3-1.6(ABS)
101		1200112-02 ZYD08BK-SPD0 1200112-02	ZYOTE 2008 SEAL PAD
102		8204010-02 ZYD08BK-SNVD 8204010-02	ZYOTE 2008 SUN VISOR LH
103		8204020-02 ZYD08BK-SNVC 8204020-02	ZYOTE 2008 SUN VISOR RH
104		476Q-1L-1207803 ZYD08BK-SNROB 476Q-1L-1207803	ZYOTE 2008 OXIGEN SENSOR



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
105		471Q-1L-1207803 ZYD08BK-SNRO 471Q-1L-1207803	ZYOTE 2008 OXIGEN SENSOR
106		SC72A2-1703020 ZYD08BK-SNRB SC72A2-1703020	ZYOTE 2008 ODOMETER SENSOR BASE
107		471Q-1L-3752950 ZYD08BK-SNR0 471Q-1L-3752950	ZYOTE 2008 KNOCK SENSOR
108		8202100-02 ZYD08BK-SMRDB 8202100-02	ZYOTE 2008 SIDE MIRROR ASSEMBLY LH
109		8202200-02 ZYD08BK-SMRCB 8202200-02	ZYOTE 2008 SIDE MIRROR ASSEMBLY RH
110		4111035-02 ZYD08BK-SLPD 4111035-02	ZYOTE 2008 SIDE TURNNING LAMP LH
111		4111040-02 ZYD08BK-SLPC 4111040-02	ZYOTE 2008 SIDE TURNNING LAMP RH
112		4111015-02 ZYD08BK-SLARF 4111015-02	ZYOTE 2008 FRONT SIGNAL LAMP LH



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
113		4111020-02 ZYD08BK-SLACF 4111020-02	ZYOTE 2008 FRONT SIGNAL LAMP RH
114		471Q-1003006 ZYD08BK-SKS0 471Q-1003006	ZYOTE 2008 SPARK PLUG GUIDE SLEEVE
115		471Q-3707801 ZYD08BK-SKC1 471Q-3707801	ZYOTE 2008 N. 1 HIGH VOLTAGE SPARK PLUG CABLE
116		471Q-3707802 ZYD08BK-SKC0 471Q-3707802	ZYOTE 2008 N. 3 HIGH VOLTAGE SPARK PLUG CABLE
117		XS6401-2810220 ZYD08BK-SKB0 XS6401-2810220	ZYOTE 2008 SHOCK ABSORPTION BLOCK
118		3105012-02 ZYD08BK-SHDW0 3105012-02	ZYOTE 2008 SPARE WHEEL SHIELD
119		3411111-02 ZYD08BK-SGRFC 3411111-02	ZYOTE 2008 STEERING GEAR FIXING CLIP SLEEVE
120		3411120-02 ZYD08BK-SGR0 3411120-02	ZYOTE 2008 STEERING GEAR FOR TRAVERSING MECHANISM



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
121		Q5100824 ZYD08BK-SFTL Q5100824	ZYOTE 2008 LOCK SHAFT
122		SH78-1602020 ZYD08BK-SFKC SH78-1602020	ZYOTE 2008 CLUTCH SEPARATE FORK
123		2906118-02 ZYD08BK-SCX2 2906118-02	ZYOTE 2008 STABILIZER ROD CUSHION II
124		2906117-02 ZYD08BK-SCX1 2906117-02	ZYOTE 2008 STABILIZER ROD CUSHION I
125		2906116-02 ZYD08BK-SCX0 2906116-02	ZYOTE 2008 STABILIZER ROD CUSHION
126		1001040-02 ZYD08BK-SARJB 1001040-02	ZYOTE 2008 REAR SHOCK ABSORBER BLOCK
127		2915010-02 ZYD08BK-SARJ 2915010-02	ZYOTE 2008 SHOCK ABSORBER REAR
128		2905100-02 ZYD08BK-SARID 2905100-02	ZYOTE 2008 SHOCK ABSORBER FRONT LEFT



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
129		2905200A02 ZYD08BK-SARICB 2905200A02	ZYOTE 2008 SHOCK ABSORBER FRONT RIGHT WITH ABS
130		2905200-02 ZYD08BK-SARIC 2905200-02	ZYOTE 2008 SHOCK ABSORBER FRONT RIGHT
131		2905100A02 ZYD08BK-SARI 2905100A02	ZYOTE 2008 SHOCK ABSORBER FRONT, LEFT WITH ABS
132		4113020-02 ZYD08BK-RVLJC 4113020-02	ZYOTE 2008 REVERSE LAMP REAR RH
133		SC72A-1703008 ZYD08BK-RSWRK SC72A-1703008	ZYOTE 2008 REVERSE SWITCH RACK
134		SC72A3-1703030 ZYD08BK-RSW0 SC72A3-1703030	ZYOTE 2008 REVERSE SWITCH
135		M18X1.5 ZYD08BK-RPL5 M18X1.5	ZYOTE 2008 RUBBER PLUG
136		8101029-02 ZYD08BK-RPL4 8101029-02	ZYOTE 2008 RUBBER PLUG



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
137		8107019-02 ZYD08BK-RPL3 8107019-02	ZYOTE 2008 RUBBER PLUG
138		8107018-02 ZYD08BK-RPL2 8107018-02	ZYOTE 2008 RUBBER PLUG
139		8107017-02 ZYD08BK-RPL1 8107017-02	ZYOTE 2008 RUBBER PLUG
140		1200111-02 ZYD08BK-RPDX 1200111-02	ZYOTE 2008 HANG RUBBER PAD, EXHAUST
141		1607119-02 ZYD08BK-RPDDH 1607119-02	ZYOTE 2008 DOUBLE HOLE RUBBER PAD
142		1302012-02 ZYD08BK-RPD0UP 1302012-02	ZYOTE 2008 UPPER RUBBER PAD--RADIATOR
143		1302013-02 ZYD08BK-RPD0LW 1302013-02	ZYOTE 2008 LOWER RUBBER PAD--RADIATOR
144		5702017-02 ZYD08BK-RONB 5702017-02	ZYOTE 2008 FIX BUTTON-TECTUM FOR ROOF INNER ORNAMENT



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
145		5702016-02 ZYD08BK-RON0 5702016-02	ZYOTE 2008 ROOF INNER ORNAMENT
146		5704015-02 ZYD08BK-ROBD 5704015-02	ZYOTE 2008 ROOF ORNAMENT BAR LH
147		5704020-02 ZYD08BK-ROBC 5704020-02	ZYOTE 2008 ROOF ORNAMENT BAR RH
148		471Q-1007013 ZYD08BK-RMSX 471Q-1007013	ZYOTE 2008 EXHAUST VALVE 1.3-1.6 L ROCKER ARM SHAFT
149		471Q-1007804 ZYD08BK-RMSW 471Q-1007804	ZYOTE 2008 INLET VALVE 1.3-1.6 L ROCKER ARM SHAFT
150		3735010-02B1 ZYD08BK-RLY0	ZYOTE 2008 RELAY ASSY
151		471Q-1007803 ZYD08BK-RK2C 471Q-1007803	ZYOTE 2008 "C" ROCKER ARM A ASSY 1.3-1.6L
152		471Q-1007802 ZYD08BK-RK2B 471Q-1007802	ZYOTE 2008 "B" ROCKER ARM A ASSY 1.3-1.6L



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
153		471Q-1007801 ZYD08BK-RK2A 471Q-1007801	ZYOTE 2008 "A" ROCKER ARM A ASSY 1.3-1.6L
154		471Q-1000024 ZYD08BK-RIGW 471Q-1000024	ZYOTE 2008 O RING FOR WATER PIPE
155		1301100-02 ZYD08BK-RDT0 1301100-02	ZYOTE 2008 RADIATOR
156		8401011-02 ZYD08BK-RDS0 8401011-02	ZYOTE 2008 RADIATOR SHROUD
157		1303022-02 ZYD08BK-RDH3 1303022-02	ZYOTE 2008 N.3 RADIATOR WATER INLET HOSE
158		1303010-02 ZYD08BK-RDH2 1303010-02	ZYOTE 2008 N.2 RADIATOR WATER INLET HOSE
159		1303021-02 ZYD08BK-RDH1 1303021-02	ZYOTE 2008 N.1 RADIATOR WATER INLET HOSE
160		1302011-02 ZYD08BK-RDB0 1302011-02	ZYOTE 2008 RADIATOR BRACKET



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
161		8105016-02 ZYD08BK-RCND 8105016-02	ZYOTE 2008 RACK CONDERSATOR LH
162		8105014-02 ZYD08BK-RCNC 8105014-02	ZYOTE 2008 RACK CONDERSATOR RH
163		8103011-02 ZYD08BK-RCM0 8103011-02	ZYOTE 2008 RELAY FOR COMPRESSOR
164		6107013-02 ZYD08BK-RBBPB 6107013-02	ZYOTE 2008 PLASTIC BUTTON--OUTER RUBBER BAR, FOR FRONT LEFT/RIGHT DOOR
165		6303018-02 ZYD08BK-RBBDSD 6303018-02	ZYOTE 2008 RUBBER BAR, DOUBLE SURFACE
166		6107010-02 ZYD08BK-RBBDD 6107010-02	ZYOTE 2008 OUTER RUBBER BAR (INCLUDE PLASTIC BUTTON) FOR FRONT LH DOOR
167		6107020-02 ZYD08BK-RBBCD 6107020-02	ZYOTE 2008 OUTER RUBBER BAR (INCLUDE PLASTIC BUTTON) FOR FRONT RIGHT DOOR
168		8401012-02 ZYD08BK-RAB0 8401012-02	ZYOTE 2008 RADIATOR CRID CLIP



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
169		6404015-02 ZYD08BK-R020 6404015-02	ZYOTE 2008 FRONT LEFT DOOR GLASS WINDOW REGULATOR ASSY
170		6404025-02 ZYD08BK-R010 6404025-02	ZYOTE 2008 FRONT RIGHT DOOR GLASS WINDOW REGULATOR ASSY
171		6204015-02 ZYD08BK-R00JDD 6204015-02	ZYOTE 2008 WINDOW REGULATOR REAR LH DOOR
172		6204020-02 ZYD08BK-R00JCD 6204020-02	ZYOTE 2008 WINDOW REGULATOR REAR RH DOOR
173		3746010-03 ZYD08BK-PWS1 3746010-03	ZYOTE 2008 POWER WINDOW SWITCH
174		3746010-02 ZYD08BK-PWS0 3746010-02	ZYOTE 2008 POWER WINDOW SWITCH
175		471Q-1-1014800 ZYD08BK-PVL0 471Q-1-1014800	ZYOTE 2008 PCV VALVE
176		471Q-0661141 ZYD08BK-PUG1 471Q-0661141	ZYOTE 2008 SCREW PLUG



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
177		476Q-1004900 ZYD08BK-PTR3B 476Q-1004900	ZYOTE 2008 OIL RING ASSY (1.6L)
178		471Q-1004900 ZYD08BK-PTR3 471Q-1004900	ZYOTE 2008 OIL RING ASSY (1.3L)
179		476Q-1004004 ZYD08BK-PTR2B 476Q-1004004	ZYOTE 2008 No. 2 PISTON RINGS(1.6L)
180		471Q-1004004 ZYD08BK-PTR2 471Q-1004004	ZYOTE 2008 No. 2 PISTON RINGS(1.3 L)
181		476Q-1004003 ZYD08BK-PTR1B 476Q-1004003	ZYOTE 2008 No. 1 PISTON RINGS (1.6L)
182		471Q-1004003 ZYD08BK-PTR1 471Q-1004003	ZYOTE 2008 No. 1 PISTON RINGS(1.3 L)
183		471Q-1004002 ZYD08BK-PTNP 471Q-1004002	ZYOTE 2008 PISTON PIN
184		476Q-1004001 ZYD08BK-PTN1 476Q-1004001	ZYOTE 2008 PISTON(1.6L A step)



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
185		471Q-1004001 ZYD08BK-PTN0 471Q-1004001	ZYOTE 2008 PISTON(1.3L A step)
186		3407020-02 ZYD08BK-PSP0 3407020-02	ZYOTE 2008 STEERING PUMP
187		471Q-1L-3813801 ZYD08BK-PSNC0 471Q-1L-3813801	ZYOTE 2008 CAMSHAFT POSITION SENSOR 1.3-1.6 L
188		3525010-02 ZYD08BK-PRVA 3525010-02	ZYOTE 2008 PROPORTIONING VALVE ASSY
189		471Q-1000015-B ZYD08BK-PLTT 471Q-1000015-B	ZYOTE 2008 PLATE FOR CRANKSHAFT POSITION SENSOR
190		471Q-1L-1003802 ZYD08BK-PLTS 471Q-1L-1003802	ZYOTE 2008 TOOTH PLATE, CAMSHAFT POSITION SENSOR 1.3-1.6L
191		471Q-1000014-B ZYD08BK-PLTPP 471Q-1000014-B	ZYOTE 2008 PRESS PLATE, TOOTH PLATE
192		5304018-02 ZYD08BK-PCPIO 5304018-02	ZYOTE 2008 FRONT PLANE CLIP



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
193		6203013-02 ZYD08BK-OWSDD2 6203013-02	ZYOTE 2008 REAR LEFT DOOR GLASS OUTER WEATHER STRIP
194		6403013-02 ZYD08BK-OWSDD1 6403013-02	ZYOTE 2008 FRONT LEFT DOOR GLASS OUTER WEATHER STRIP
195		6203014-02 ZYD08BK-OWSCD2 6203014-02	ZYOTE 2008 REAR RIGHT DOOR GLASS OUTER WEATHER STRIP
196		6403014-02 ZYD08BK-OWSCD1 6403014-02	ZYOTE 2008 FRONT RIGHT DOOR GLASS OUTER WEATHER STRIP
197		476Q-6L-1300007 ZYD08BK-OWPT 476Q-6L-1300007	ZYOTE 2008 T-TUBE WATER OUTLET
198		476Q-6L-1300804 ZYD08BK-OWPRD0 476Q-6L-1300804	ZYOTE 2008 WATER OUTLET RIND ASSY
199		1303015-02 ZYD08BK-OWP0 1303015-02	ZYOTE 2008 RADIATOR OUTLET WATER PIPE
200		6105055-02 ZYD08BK-OSHD0 6105055-02	ZYOTE 2008 OUT SIDE HANDLE LH



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
201		6105060-02 ZYD08BK-OSHC0 6105060-02	ZYOTE 2008 OUT SIDE HANDLE RH
202		471Q-1002801 ZYD08BK-OSCF 471Q-1002801	ZYOTE 2008 CRANKSHAFT SEAL REAR
203		471Q-1011800-B ZYD08BK-OSCF 471Q-1011800-B	ZYOTE 2008 CRANKSHAFT OIL SEAL FRONT
204		5304015-02 ZYD08BK-ORNDC 5304015-02	ZYOTE 2008 ORNAMENT LH FOR FRONT WALL COWL BAR COVER
205		5304020-02 ZYD08BK-ORNCC 5304020-02	ZYOTE 2008 ORNAMENT RH FOR FRONT WALL COWL BAR COVER
206		476Q-6L-1000803 ZYD08BK-ORL0 476Q-6L-1000803	ZYOTE 2008 OIL RULER ASSY
207		8403026-02 ZYD08BK-OPTIDM 8403026-02	ZYOTE 2008 MIDDLE ORNAMENT PLATE FOR FRONT LEFT MUDGUARD
208		8403017-02 ZYD08BK-OPTIDF 8403017-02	ZYOTE 2008 FRONT ORNAMENT PLATE FOR FRONT LH MUDGUARD



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
209		8403031-02 ZYD08BK-OPTICM 8403031-02	ZYOTE 2008 MIDDLE ORNAMENT PLATE FOR FRONT RIGHT MUDGUARD
210		8403018-02 ZYD08BK-OPTICF 8403018-02	ZYOTE 2008 FRONT ORNAMENT PLATE FOR FRONT RH MUDGUARD
211		471Q-1011950-B ZYD08BK-OP10A 471Q-1011950-B	ZYOTE 2008 OIL PUMP ASSY
212		471Q-1011950 ZYD08BK-OP10 471Q-1011950	ZYOTE 2008 OIL PUMP ASSY
213		6202055-02 ZYD08BK-OORJED 6202055-02	ZYOTE 2008 REAR DOOR OUTER EDGE ORNAMENT, LH
214		6202060-02 ZYD08BK-OORJEC 6202060-02	ZYOTE 2008 REAR DOOR OUTER EDGE ORNAMENT, RH
215		8404015-02 ZYD08BK-OORJDW 8404015-02	ZYOTE 2008 BODY WHEEL OUTER ORNAMENT REAR LH
216		8404020-02 ZYD08BK-OORJCW 8404020-02	ZYOTE 2008 BODY WHEEL OUTER ORNAMENT REAR RH



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
217		8403035-02 ZYD08BK-OORIDW 8403035-02	ZYOTE 2008 BODY WHEEL OUTER ORNAMENT FRONT LH
218		6402055-02 ZYD08BK-OORID 6402055-02	ZYOTE 2008 FRONT DOOR OUTER ORNAMENT LH
219		8403040-02 ZYD08BK-OORICW 8403040-02	ZYOTE 2008 BODY WHEEL OUTER ORNAMENT FRONT RH
220		6402060-02 ZYD08BK-OORIC 6402060-02	ZYOTE 2008 FRONT DOOR OUTER ORNAMENT RH
221		6202053-02 ZYD08BK-OOBJDD 6202053-02	ZYOTE 2008 DOOR OUTER ORNAMENT BRACKET REAR LH
222		6202054-02 ZYD08BK-OOBJCD 6202054-02	ZYOTE 2008 DOOR OUTER ORNAMENT BRACKET REAR RH
223		3408010-02 ZYD08BK-OLT0 3408010-02	ZYOTE 2008 STEERING OIL POT
224		471Q-3810950 ZYD08BK-OLS0 471Q-3810950	ZYOTE 2008 OIL PRESSURE SENSORS



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
225		1104216-02 ZYD08BK-OLP5 1104216-02	ZYOTE 2008 OIL PIPE NO.5
226		1104214-02 ZYD08BK-OLP4 1104214-02	ZYOTE 2008 OIL PIPE NO.4
227		1104213-02 ZYD08BK-OLP3 1104213-02	ZYOTE 2008 OIL PIPE NO.3
228		1104212-02 ZYD08BK-OLP2 1104212-02	ZYOTE 2008 OIL PIPE NO.2
229		1104205-02 ZYD08BK-OLP1 1104205-02	ZYOTE 2008 OIL PIPE NO.1
230		SC-1802504 ZYD08BK-OIS1 SC-1802504	ZYOTE 2008 OIL SEAL
231		471Q-1003803 ZYD08BK-OIS0 471Q-1003803	ZYOTE 2008 OIL SEAL
232		476Q-6L-1012950 ZYD08BK-OFEA 476Q-6L-1012950	ZYOTE 2008 OIL FILTER



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
233		71Q-1000804 ZYD08BK-OCPO 71Q-1000804	ZYOTE 2008 FILLING OIL CAP
234		476Q-6L-1010950 ZYD08BK-OCA0 476Q-6L-1010950	ZYOTE 2008 OIL COLLECTOR ASSY
235		476Q-6L-1009800 ZYD08BK-OBS0 476Q-6L-1009800	ZYOTE 2008 OIL BASIN
236		1109011-02 ZYD08BK-OAPAF 1109011-02	ZYOTE 2008 AIR FILTER OUTLET PIPE
237		471Q-1007008 ZYD08BK-NUTVC 471Q-1007008	ZYOTE 2008 ADJUST NUT, VALVE CLEARANCE
238		2803027-02 ZYD08BK-NUTPF 2803027-02	ZYOTE 2008 PLASTIC NUT FOR FRONT BUMPER
239		6202011-02 ZYD08BK-NUTP1 6202011-02	ZYOTE 2008 PLASTIC NUT
240		6202052-02 ZYD08BK-NUTPO 6202052-02	ZYOTE 2008 PLASTIC NUT



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
241		8403013-02 ZYD08BK-NUTP 8403013-02	ZYOTE 2008 PLASTIC NUT
242		2201126-02 ZYD08BK-NDV0 2201126-02	ZYOTE 2008 BOLT FOR TRANSMISSION SHAFT
243		8201012-02 ZYD08BK-MRBJ 8201012-02	ZYOTE 2008 INNER MIRROR BASE
244		8201010-02 ZYD08BK-MR0I 8201010-02	ZYOTE 2008 INNER MIRROR
245		476Q-6L-1008901 ZYD08BK-MNFX 476Q-6L-1008901	ZYOTE 2008 MANIFOLD EX.ASSY
246		471Q-6L-1008900 ZYD08BK-MNFW 471Q-6L-1008900	ZYOTE 2008 MANIFOLD IN.
247		4108010-02 ZYD08BK-LMPJP 4108010-02	ZYOTE 2008 REAR LICENSE PLATE LAMP
248		4104010-02 ZYD08BK-LMP0 4104010-02	ZYOTE 2008 ROOM LAMP (STANDARD)



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
249		6305020-02 ZYD08BK-LMCTD 6305020-02	ZYOTE 2008 LOCK MECHANISM ASSY, TAIL DOR
250		6205015-02 ZYD08BK-LMCJDD 6205015-02	ZYOTE 2008 LOCK MECHANISM ASSY, REAR LH DOOR (STANDARD)
251		6205020-02 ZYD08BK-LMCJCD 6205020-02	ZYOTE 2008 LOCK MECHANISM ASSY, REAR RH DOOR (STANDARD)
252		6105015B02 ZYD08BK-LMCIDD1 6105015B02	ZYOTE 2008 LOCK MECHANISM ASSY, FRONT LH DOOR (FASHION)
253		6105015-02 ZYD08BK-LMCIDD 6105015-02	ZYOTE 2008 LOCK MECHANISM ASSY, FRONT LH DOOR (STANDARD)
254		6105020B02 ZYD08BK-LMCICD1 6105020B02	ZYOTE 2008 LOCK MECHANISM ASSY, FRONT RH DOOR (FASHION)
255		6105020-02 ZYD08BK-LMCICD 6105020-02	ZYOTE 2008 LOCK MECHANISM ASSY, FRONT RH DOOR (STANDARD)
256		SC72A-1703024 ZYD08BK-LKP0 SC72A-1703024	ZYOTE 2008 ODOMETER SENSOR BASE LOCK PLATE



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
257		6206400-02 ZYD08BK-LHNJD 6206400-02	ZYOTE 2008 LH DOOR LOWER HINGE REAR
258		6206300-02 ZYD08BK-LHNJC 6206300-02	ZYOTE 2008 RH DOOR LOWER HINGE REAR
259		5108015-02 ZYD08BK-LGSSB 5108015-02	ZYOTE 2008 SUNDRIES BOX, LUGGAGE CABIN
260		6313022-02 ZYD08BK-LCZTDA 6313022-02	ZYOTE 2008 LOCALIZER (ANODE) TAIL DOOR
261		6313021-02 ZYD08BK-LCZTD 6313021-02	ZYOTE 2008 LOCALIZER (CATHODE) TAIL DOOR
262		1703020-02 ZYD08BK-LBB0A 1703020-02	ZYOTE 2008 LEVER BOOT ASSY
263		17033095-02S ZYD08BK-KGS1B 17033095-02S	ZYOTE 2008 KNOB LEVER (ALMONDWOOD, FASHION)
264		1703095-02S ZYD08BK-KGS1 1703095-02S	ZYOTE 2008 KNOB LEVER (ALMONDWOOD, FASHION)



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei,Taiwan,R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
265		1703095-02 ZYD08BK-KGS0 1703095-02	ZYOTE 2008 KNOB LEVER (STANDARD)
266		3913010-02 ZYD08BK-JCK0	ZYOTE 2008 JACK ASSY
267		6203016-02 ZYD08BK-IWSJ0 6203016-02	ZYOTE 2008 REAR DOOR GLASS INNER WEATHERSTRIP
268		6403016-02 ZYD08BK-IWSI0 6403016-02	ZYOTE 2008 FRONT DOOR GLASS INNER WEATHERSTRIP
269		476Q-6L-1300802 ZYD08BK-IWPA 476Q-6L-1300802	ZYOTE 2008 INLET WATER PIPE ASSY
270		476Q-6L-1000022 ZYD08BK-IWPO 476Q-6L-1000022	ZYOTE 2008 INLET WATER PIPE
271		6302016-02 ZYD08BK-IORTD 6302016-02	ZYOTE 2008 TAIL DOOR INNER ORNAMENT
272		6202019-02 ZYD08BK-IORPB 6202019-02	ZYOTE 2008 PLASTIC BUTTON--INNER ORNAMENTE DOOR



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
273		6202017A02 ZYD08BK-IORJDA 6202017A02	ZYOTE 2008 REAR LEFT DOOR INNER ORNAMENT
274		6202017-02 ZYD08BK-IORJD 6202017-02	ZYOTE 2008 REAR LEFT DOOR INNER ORNAMENT
275		6202018A02 ZYD08BK-IORJCA 6202018A02	ZYOTE 2008 REAR RIGHT DOOR INNER ORNAMENT
276		6202018-02 ZYD08BK-IORJC 6202018-02	ZYOTE 2008 REAR RIGHT DOOR INNER ORNAMENT
277		6402035-02 ZYD08BK-IORIDT 6402035-02	ZYOTE 2008 FRONT DOOR TRIANGLE INNER ORNAMENT LH
278		6402017-02 ZYD08BK-IORID 6402017-02	ZYOTE 2008 FRONT LH DOOR INNER ORNAMENT
279		6402040-02 ZYD08BK-IORICT 6402040-02	ZYOTE 2008 FRONT DOOR TRIANGLE INNER ORNAMENT RH
280		6402018-02 ZYD08BK-IORIC 6402018-02	ZYOTE 2008 FRONT RH DOOR INNER ORNAMENT



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
281		6202035-02 ZYD08BK-IOORJDT 6202035-02	ZYOTE 2008 REAR DOOR TRIANGLE OUTER ORNAMENT LH
282		6202040-02 ZYD08BK-IOORJCT 6202040-02	ZYOTE 2008 REAR DOOR TRIANGLE OUTER ORNAMENT RH
283		6202012-02 ZYD08BK-IOB0D 6202012-02	ZYOTE 2008 DOOR INNER ORNAMENT BRACKET
284		6105075-02 ZYD08BK-INHD1 6105075-02	ZYOTE 2008 INSIDE HANDLE LH DOOR
285		6105075-02 ZYD08BK-INHD0 6105075-02	ZYOTE 2008 INSIDE HANDLE LH DOOR (STANDARD)
286		6105080A02 ZYD08BK-INHC2 6105080A02	ZYOTE 2008 INSIDE HANDLE RH DOOR(APPLICATION SILVER)
287		6105080-02 ZYD08BK-INHC1 6105080-02	ZYOTE 2008 INSIDE HANDLE RH DOOR
288		6105080-02 ZYD08BK-INHC0 6105080-02	ZYOTE 2008 INSIDE HANDLE RH DOOR (STANDARD)



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
289		2803021-02 ZYD08BK-INCB 2803021-02	ZYOTE 2008 BUMPER INFLATE SCREW
290		8403019-02 ZYD08BK-INC2 8403019-02	ZYOTE 2008 INFLATE SCREW FOR FRONT WING
291		471Q-1L-1112950 ZYD08BK-IJT0A 471Q-1L-1112950	ZYOTE 2008 FUEL INJECTOR ASSY
292		370401002A1 ZYD08BK-IGS1B 370401002A1	ZYOTE 2008 IGNITION SWITCH
293		3704010-02 ZYD08BK-IGS0A 3704010-02	ZYOTE 2008 IGNITION SWITCH ASSY
294		471Q-2L-3705800 ZYD08BK-IGS0 471Q-2L-3705800	ZYOTE 2008 IGNITION SWITCH
295		6202021A02 ZYD08BK-ICRD1 6202021A02	ZYOTE 2008 DOOR INNER CRAMP RING LH (FASHION)
296		6202021-02 ZYD08BK-ICRD0 6202021-02	ZYOTE 2008 DOOR INNER CRAMP RING LH (STANDARD)



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
297		6202021-02 ZYD08BK-ICRD 6202021-02	ZYOTE 2008 DOOR INNER CRAMP RING LH
298		6202022A02 ZYD08BK-ICRC1 6202022A02	ZYOTE 2008 DOOR INNER CRAMP RING RH (FASHION)
299		6202022-02 ZYD08BK-ICRC0 6202022-02	ZYOTE 2008 DOOR INNER CRAMP RING RH (STANDARD)
300		6202022-02 ZYD08BK-ICRC 6202022-02	ZYOTE 2008 DOOR INNER CRAMP RING RH
301		1109012-02 ZYD08BK-IAPAF 1109012-02	ZYOTE 2008 AIR FILTER INLET PIPE
302		476Q-6L-1000808 ZYD08BK-HSD0 476Q-6L-1000808	ZYOTE 2008 EXHAUST HEAT SHIELD
303		6302025-02 ZYD08BK-HORTD 6302025-02	ZYOTE 2008 TAIL DOOR HINGE ORNAMENT
304		209110-02 ZYD08BK-HOPTX 209110-02	ZYOTE 2008 TAIL PIPE, EXHAUST



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
305		8108020-02 ZYD08BK-HOPL2 8108020-02	ZYOTE 2008 2# LOW PRESSURE PIPE GROUP
306		8108010-02 ZYD08BK-HOPL1 8108010-02	ZYOTE 2008 1# LOW PRESSURE PIPE GROUP
307		1201100-02 ZYD08BK-HOPJEX 1201100-02	ZYOTE 2008 REAR PIPE , EXHAUST
308		1205100-02 ZYD08BK-HOPIEX 1205100-02	ZYOTE 2008 FRONT PIPE, EXHAUST
309		8108060-02 ZYD08BK-HOPH4 8108060-02	ZYOTE 2008 4# HIGH PRESSURE PIPE GROUP
310		8108050-02 ZYD08BK-HOPH3 8108050-02	ZYOTE 2008 3# HIGH PRESSURE PIPE GROUP
311		8108040-02 ZYD08BK-HOPH2 8108040-02	ZYOTE 2008 2# HIGH PRESSURE PIPE GROUP
312		8108030-02 ZYD08BK-HOPH1 8108030-02	ZYOTE 2008 1# HIGH PRESSURE PIPE GROUP



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
313		8111010-02 ZYD08BK-HOP1 8111010-02	ZYOTE 2008 AIR GUIDE PIPE
314		6205063-02 ZYD08BK-HNRD0 6205063-02	ZYOTE 2008 INNER HANDLE ROD FOR REAR LEFT DOOR LOCK
315		6205064-02 ZYD08BK-HNRC0 6205064-02	ZYOTE 2008 INNER HANDLE ROD FOR REAR RIGHT DOOR LOCK
316		3402200-02 ZYD08BK-HNC0 3402200-02	ZYOTE 2008 HORN COVER ASSY
317		4101015-02 ZYD08BK-HLPD 4101015-02	ZYOTE 2008 HEAD LAMP LH
318		4101020-02 ZYD08BK-HLPC 4101020-02	ZYOTE 2008 HEAD LAMP RH
319		6306100-02 ZYD08BK-HINTD 6306100-02	ZYOTE 2008 TAIL DOR HINGE
320		6106200-02 ZYD08BK-HINIA 6106200-02	ZYOTE 2008 RH DOOR UPPER / LH DOOR LOWER, HINGE FRONT



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
321		6106100-02 ZYD08BK-HINI0 6106100-02	ZYOTE 2008 RH DOOR LOWER / LH DOOR UPPER, HINGE FRONT
322		8101020-02 ZYD08BK-HHOA 8101020-02	ZYOTE 2008 HEATER ASSY
323		XS6401-1315003 ZYD08BK-HHO3 XS6401-1315003	ZYOTE 2008 N.3 HEATER HOSE
324		8101033-02 ZYD08BK-HHO2 8101033-02	ZYOTE 2008 N.2 HEATER HOSE
325		8101031-02 ZYD08BK-HHO1 8101031-02	ZYOTE 2008 N.1 HEATER HOSE
326		8101032-02 ZYD08BK-HHO0 8101032-02	ZYOTE 2008 N.1 HEATER HOSE
327		3508100-02 ZYD08BK-HDLG 3508100-02	ZYOTE 2008 HANDLE
328		4134010E02 ZYD08BK-HBL1 4134010E02	ZYOTE 2008 HIGH BRAKE LAMP



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
329		4134010-02 ZYD08BK-HBL0 4134010-02	ZYOTE 2008 HIGH BRAKE LIGHT
330		476Q-1000039 ZYD08BK-GTH0 476Q-1000039	ZYOTE 2008 THROTTLE GASKET
331		1001055-02 ZYD08BK-GTDD 1001055-02	ZYOTE 2008 HANDING GASKET LH
332		1001060-02 ZYD08BK-GTDC 1001060-02	ZYOTE 2008 HANDING GASKET RH
333		471Q-1000005 ZYD08BK-GT60 471Q-1000005	ZYOTE 2008 MANIFOLD GASKET EXHAUST
334		471Q-1000004 ZYD08BK-GT50 471Q-1000004	ZYOTE 2008 MANIFOLD GASKET INLET
335		471Q-1000807 ZYD08BK-GT31 471Q-1000807	ZYOTE 2008 1.3 CYL HEAD GASKET
336		476Q-1000807 ZYD08BK-GT30 476Q-1000807	ZYOTE 2008 1.6 CYL HEAD GASKET



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
337		6201255-02 ZYD08BK-GSRJDD 6201255-02	ZYOTE 2008 REAR LH DOOR, GLASS RAIL
338		6201155-02 ZYD08BK-GSRJCD 6201155-02	ZYOTE 2008 REAR RH DOOR, GLASS RAIL
339		1703130-02 ZYD08BK-GSL1 1703130-02	ZYOTE 2008 SHIFT LEVER ASSY
340		1703100-02 ZYD08BK-GSL0 1703100-02	ZYOTE 2008 SHIFT LEVER ASSY
341		1703140-02 ZYD08BK-GSC0 1703140-02	ZYOTE 2008 GEAR SHIFT CABLE
342		6404020-02 ZYD08BK-GRRIDD 6404020-02	ZYOTE 2008 FRONT LH DOOR GLASS REAR RAIL
343		6404040-02 ZYD08BK-GRRICD 6404040-02	ZYOTE 2008 FRONT RH DOOR GLASS REAR RAIL
344		5403020-02 ZYD08BK-GRCC 5403020-02	ZYOTE 2008 REAR TRIANGLE GLASS RH



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
345		2911035-02 ZYD08BK-GLAU 2911035-02	ZYOTE 2008 UPPER CONTROL ARM ASSY
346		2911040-02 ZYD08BK-GLAL 2911040-02	ZYOTE 2008 LOWER CONTROL ARM ASSY
347		6404010-02 ZYD08BK-GFRIDD 6404010-02	ZYOTE 2008 FRONT LH DOOR GLASS FRONT RAIL
348		6404030-02 ZYD08BK-GFRICD 6404030-02	ZYOTE 2008 FRONT RH DOOR GLASS FRONT RAIL
349		471Q-1L-3701950 ZYD08BK-GEN0A 471Q-1L-3701950	ZYOTE 2008 GENERATOR ASSY
350		471Q-1L-3701959 ZYD08BK-GEN0 471Q-1L-3701959	ZYOTE 2008 GENERATOR ASSY
351		8215011-02 ZYD08BK-GDBW 8215011-02	ZYOTE 2008 INNER GUARD BAR, DOOR (STANDARD)
352		1701100-02 ZYD08BK-GBX0 1701100-02	ZYOTE 2008 GEAR BOX ASSEMBLY



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
353		476Q-1L-1000802 ZYD08BK-G080 476Q-1L-1000802	ZYOTE 2008 CRANKSHAFT TIMING GEAR ASSY
354		3703040-02 ZYD08BK-FXR0B 3703040-02	ZYOTE 2008 BATTERY FIX RACK
355		5702018-02 ZYD08BK-FXBTC 5702018-02	ZYOTE 2008 FIX BUTTON 2 - TECTUM
356		6202039-02 ZYD08BK-FXBOO 6202039-02	ZYOTE 2008 REAR DOOR OUTER TRIANGLE ORNAMENT FIX BUTTON
357		5109012-02 ZYD08BK-FXBIC0 5109012-02	ZYOTE 2008 FRONT CARPET FIX BUTTON
358		1104016-02 ZYD08BK-FXBFP 1104016-02	ZYOTE 2008 FIX BUTTON
359		8402013-02 ZYD08BK-FXBB 8402013-02	ZYOTE 2008 FIXING BUTTON 1-- BONNET KNIGHTHEAD
360		8402027-02 ZYD08BK-FXB0 8402027-02	ZYOTE 2008 FIX BUTTON



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
361		471Q-1005004 ZYD08BK-FWB0 471Q-1005004	ZYOTE 2008 FLYWHEEL BOLT
362		476Q-5L-1005900 ZYD08BK-FW10 476Q-5L-1005900	ZYOTE 2008 FLYWHEEL ASSY
363		1101100-02 ZYD08BK-FTK0 1101100-02	ZYOTE 2008 FUEL TANK
364		3722010-02 ZYD08BK-FSB0 3722010-02	ZYOTE 2008 FUSE BOX
365		471Q-1L-1104800 ZYD08BK-FRL0 471Q-1L-1104800	ZYOTE 2008 FUEL RAIL
366		5306265A02 ZYD08BK-FPNB 5306265A02	ZYOTE 2008 CENTER PANEL , INSTRUMENT BOARD (FASHION)
367		5306265-02 ZYD08BK-FPNA 5306265-02	ZYOTE 2008 CENTER PANEL , INSTRUMENT BOARD (BLACK , STANDARD)
368		4116015-02 ZYD08BK-FOLD0 4116015-02	ZYOTE 2008 FOG LAMP LH



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
369		471Q-1007010 ZYD08BK-FLB0 471Q-1007010	ZYOTE 2008 FLANGE BOLT
370		1106010-02B1 ZYD08BK-FIP0 1106010-02B1	ZYOTE 2008 FUEL PUMP ASSY
371		1104013 ZYD08BK-FIIL 1104013	ZYOTE 2008 FUEL FILLING HOSE LOWER
372		1104017-02 ZYD08BK-FIIA 1104017-02	ZYOTE 2008 FUEL FILLING HOSE ASSY
373		1104217-02 ZYD08BK-FIIO 1104217-02	ZYOTE 2008 N. 6 FUEL PIPE
374		4116030-02 ZYD08BK-FGSJ0 4116030-02	ZYOTE 2008 FOG LAMP SWITCH REAR
375		4116030-02 ZYD08BK-FGSI0 4116030-02	ZYOTE 2008 FOG LAMP SWITCH FRONT
376		1117010-02 ZYD08BK-FFE0 1117010-02	ZYOTE 2008 FUEL FILTER



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
377		1104020-02 ZYD08BK-FCPF0 1104020-02	ZYOTE 2008 FUEL FILLING HOSE CAP
378		471Q-1000804 ZYD08BK-FCP0 471Q-1000804	ZYOTE 2008 FUEL CAP
379		2803010-02G ZYD08BK-FBU1 2803010-02G	ZYOTE 2008 FRONT BUMPER(NEW STYLE)
380		2803011-02 ZYD08BK-FBU0 2803011-02	ZYOTE 2008 FRONT BUMPER(OLD SLYLE)
381		2803030-02 ZYD08BK-FBMF 2803030-02	ZYOTE 2008 FIX BEAM FOR FRONT BUMPER
382		1308100-02 ZYD08BK-FANE 1308100-02	ZYOTE 2008 ELECTRIC FAN
383		1311110-02 ZYD08BK-EXT0 1311110-02	ZYOTE 2008 EXPANSION TANK
384		8107010-02 ZYD08BK-EVB0A 8107010-02	ZYOTE 2008 EVAPOTARION BOX ASSY



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
385		476Q-1007002 ZYD08BK-EV1X6 476Q-1007002	ZYOTE 2008 1.6L ENGINE VALVE EX.
386		471Q-1007002 ZYD08BK-EV1X3 471Q-1007002	ZYOTE 2008 1.3L ENGINE VALVE EX.
387		476Q-1007001 ZYD08BK-EV1W6 476Q-1007001	ZYOTE 2008 1.6L ENGINE VALVE IN.
388		471Q-1007001 ZYD08BK-EV1W3 471Q-1007001	ZYOTE 2008 1.3L ENGINE VALVE IN.
389		1000100-03 ZYD08BK-ENG1 1000100-03	ZYOTE 2008 ENGINE ASSEMBLY (1.3L)
390		1000100-02 ZYD08BK-ENG0 1000100-02	ZYOTE 2008 ENGINE ASSEMBLY (1.6L)
391		1001015-02 ZYD08BK-EMTD 1001015-02	ZYOTE 2008 ENGINE MOUNTING LH(ENGINE LEFT RACK GROUP)
392		1001020-02 ZYD08BK-EMTC 1001020-02	ZYOTE 2008 ENGINE MOUNTING RH(ENGINE RIGHT RACK GROUP)



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
393		3721010-02B1 ZYD08BK-ELH0 3721010-02B1	ZYOTE 2008 ELECTRICAL HORN
394		471Q-1004011 ZYD08BK-EB30 471Q-1004011	ZYOTE 2008 ENGINE CON ROD BEARING (A step)
395		6105021-02 ZYD08BK-DWLIDD 6105021-02	ZYOTE 2008 FRONT LEFT DOOR LOCK BUTTON DRAW LINK
396		6105022-02 ZYD08BK-DWLICD 6105022-02	ZYOTE 2008 FRONT RIGHT DOOR LOCK BUTTON DRAW LINK
397		3404112-02 ZYD08BK-DTSC 3404112-02	ZYOTE 2008 DUSTPROOF SLEEVE CAP FOR STEERING SHAFT
398		3404111-02 ZYD08BK-DTS0 3404111-02	ZYOTE 2008 DUSTPROOF SLEEVE FOR STEERING SHAFT
399		2201100-02 ZYD08BK-DRSA6 2201100-02	ZYOTE 2008 TRANSMISSION SHAFT ASSY 1.6L
400		2201100-03B ZYD08BK-DRSA3 2201100-03B	ZYOTE 2008 TRANSMISSION SHAFT ASSY 1.6L



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
401		6301100-02 ZYD08BK-DORTD 6301100-02	ZYOTE 2008 DOOR WELDING ASSY, TAIL DOR
402		6201200-02 ZYD08BK-DORJD 6201200-02	ZYOTE 2008 DOOR WELDING ASSY, REAR LH
403		6201100-02 ZYD08BK-DORJC 6201100-02	ZYOTE 2008 DOOR WELDING ASSY, REAR RH
404		6101200-02 ZYD08BK-DORD1 6101200-02	ZYOTE 2008 FRONT LEFT DOOR ASSEMBLY
405		6101100-02 ZYD08BK-DORC1 6101100-02	ZYOTE 2008 RIGHT LEFT DOOR ASSEMBLY
406		6205043-02 ZYD08BK-DOHJ1 6205043-02	ZYOTE 2008 CLIP I- REAR DOOR HANDLE
407		4104030-02 ZYD08BK-DLS0 4104030-02	ZYOTE 2008 DOOR LAMP SWITCH
408		6105023-02 ZYD08BK-DLKB 6105023-02	ZYOTE 2008 DOOR LOCK BUTTON BASE



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
409		6105053-02 ZYD08BK-DLK0 6105053-02	ZYOTE 2008 DOOR LOCK LOOP
410		1104520-02 ZYD08BK-DGCFH 1104520-02	ZYOTE 2008 DRAG CABLE FOR FUEL FILLING HOSE CAP
411		1001012-02 ZYD08BK-CWSU 1001012-02	ZYOTE 2008 UP RUSH WASHER DRIVE SHAFT RACK
412		1001013-02 ZYD08BK-CWSL 1001013-02	ZYOTE 2008 UNDER RUSH WASHER DRIVE SHAFT RACK
413		1001014-02 ZYD08BK-CVRTR1 1001014-02	ZYOTE 2008 LIMIT COVER FOR TRANSMISSION RACK
414		2916113-02 ZYD08BK-CVRTR0 2916113-02	ZYOTE 2008 COVER FOR TRANSY STABILIZER ROD
415		1001014 ZYD08BK-CVRTR 1001014	ZYOTE 2008 LIMIT COVER FOR TRANSMISSION RACK
416		471Q-1-1014801 ZYD08BK-CVRA 471Q-1-1014801	ZYOTE 2008 VALVE-ROCKER ARM CHAMBER COVER ASSY



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
417		2916112-02 ZYD08BK-CUXTR 2916112-02	ZYOTE 2008 CUSHION FOR TRANSY STABILIZER ROD
418		6313023-02 ZYD08BK-CUXTD 6313023-02	ZYOTE 2008 TAIL DOOR CUSHION
419		2911022-02 ZYD08BK-CUXJS 2911022-02	ZYOTE 2008 REAR SHOCK ABSORVER CUSHION--REAR SUSPENSION FRAME ASSY
420		8402014-02 ZYD08BK-CUXB 8402014-02	ZYOTE 2008 BONNET CUSHION
421		2905023-02 ZYD08BK-CUX1 2905023-02	ZYOTE 2008 CUSHION
422		SC-1703003 ZYD08BK-CUX0 SC-1703003	ZYOTE 2008 CUSHION
423		5304011-02 ZYD08BK-CSAU 5304011-02	ZYOTE 2008 UPPER SEAL FOR COWL BAR COVER
424		SH78-1602030 ZYD08BK-CS10 SH78-1602030	ZYOTE 2008 CLUTCH SLAVE CYLINDER



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
425		1130200-02 ZYD08BK-CRN0 1130200-02	ZYOTE 2008 CARBON CANISTER
426		SH78-1602010 ZYD08BK-CRG0 SH78-1602010	ZYOTE 2008 CLUTCH RELEASE BEARING
427		5109031-02 ZYD08BK-CPTR 5109031-02	ZYOTE 2008 REAR FLOOR CARPET (STANDARD)
428		471Q-1003014 ZYD08BK-CNV0 471Q-1003014	ZYOTE 2008 CONNECT VALVE
429		3774010-02 ZYD08BK-CNS0 3774010-02	ZYOTE 2008 COMBINATION SWITCH
430		471Q-1004901 ZYD08BK-CNR0 471Q-1004901	ZYOTE 2008 CONNECTING ROD
431		8112010-02 ZYD08BK-CNP0 8112010-02	ZYOTE 2008 AIR CONDITIONING CONTROL PANEL ASSY
432		2916111-02 ZYD08BK-CNLJ 2916111-02	ZYOTE 2008 CONNECTING LINK--REAR SUSPENSION FRAME STABILIZATION PLANT



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
433		471Q-1006950 ZYD08BK-CMT0 471Q-1006950	ZYOTE 2008 1.3-1.6 L CAMSHAFT
434		471Q-1003804 ZYD08BK-CMSJ 471Q-1003804	ZYOTE 2008 CAMSHAFT REAR OIL SEAL 1.3 - 1.6 L
435		1608200-02 ZYD08BK-CMC0 1608200-02	ZYOTE 2008 CLUTCH MASTER CYLINDER
436		2911023-02 ZYD08BK-CLS1 2911023-02	ZYOTE 2008 COILED SPRING--REAR SUSPENSION FRAME ASSY
437		2905204-02 ZYD08BK-CLS0 2905204-02	ZYOTE 2008 COIL SPRING (SHOCK ABOsorBER FRONT)
438		471Q-1003800 ZYD08BK-CLH1 471Q-1003800	ZYOTE 2008 1.3 CYLINDER HEAD ASSEMBLY
439		476Q-1003800 ZYD08BK-CLH0 476Q-1003800	ZYOTE 2008 1.6L CYLINDER HEAD SUBASSY
440		471Q-1005001-B ZYD08BK-CKSA 471Q-1005001-B	ZYOTE 2008 CRANKSHAFT(1.3L)



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
441		476Q-22-1005001 ZYD08BK-CKS0 476Q-22-1005001	ZYOTE 2008 CRANKSHAFT(1.6L)
442		471Q-1002013 ZYD08BK-CFB2 471Q-1002013	ZYOTE 2008 UPPER MAIN CRANKSHAFT BRASS (1 STEP)
443		471Q-1002012 ZYD08BK-CFB1 471Q-1002012	ZYOTE 2008 LOWER MAIN CRANKSHAFT BRASS (1 STEP)
444		471Q-1002011 ZYD08BK-CFB0 471Q-1002011	ZYOTE 2008 MIDDLE MAIN CRANKSHAFT BRASS (1 STEP)
445		8105010-02B1 ZYD08BK-CDNA 8105010-02B1	ZYOTE 2008 CONDENSER ASSY
446		471Q-1600800 ZYD08BK-CDCP 471Q-1600800	ZYOTE 2008 CLUTCH PRESS DISC ASSY 1.3-1.6L
447		476Q-6L-1600801 ZYD08BK-CDC0 476Q-6L-1600801	ZYOTE 2008 CLUTCH DRIVEN DISC 1.3-1.6 L
448		3774022-02 ZYD08BK-CCV0LW 3774022-02	ZYOTE 2008 LOWER COVER , STEERING SHAFT



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei,Taiwan,R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
449		5306255-02 ZYD08BK-CBMRC 5306255-02	ZYOTE 2008 TRIM COVER , COMBINATION METER (BLACK)
450		3820010A02 ZYD08BK-CBM6B 3820010A02	ZYOTE 2008 COMBINATION METER (1.6 L FASHION)
451		3820010-02 ZYD08BK-CBM6A 3820010-02	ZYOTE 2008 COMBINATION METER (1.6 L)
452		3820010-03 ZYD08BK-CBM3A 3820010-03	ZYOTE 2008 COMBINATION METER (1.3 L)
453		4133015-02 ZYD08BK-CBLJD 4133015-02	ZYOTE 2008 COMBINATION LAMP REAR LH
454		4133020-02 ZYD08BK-CBLJC 4133020-02	ZYOTE 2008 COMBINATION LAMP REAR RH
455		476Q-6L-1002901 ZYD08BK-CBK0B 476Q-6L-1002901	ZYOTE 2008 CYLINDER BLOCK ASSY (1.6L)
456		471Q-6L-1002091 ZYD08BK-CBK0A 471Q-6L-1002091	ZYOTE 2008 1.3 CYLINDER BLOCK ASSY



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
457		471Q-6L-1002901 ZYD08BK-CBK0 471Q-6L-1002901	ZYOTE 2008 CYL. BLOCK ASSY (1.3L)
458		471Q-1002009 ZYD08BK-CAPOS 471Q-1002009	ZYOTE 2008 CRANKSHAFT OIL SEAL CAP
459		471Q-1007009 ZYD08BK-CAPAR 471Q-1007009	ZYOTE 2008 ROCKER ARM SHAFT CAP
460		471Q-0140207 ZYD08BK-BWS3 471Q-0140207	ZYOTE 2008 BOLT AND WASHER ASSY
461		471Q-0240063 ZYD08BK-BWS2 471Q-0240063	ZYOTE 2008 BOLT AND WASHER ASSY
462		471Q-0241264 ZYD08BK-BWS1 471Q-0241264	ZYOTE 2008 BOLT AND WASHER ASSY
463		3502050-02 ZYD08BK-BWCJD 3502050-02	ZYOTE 2008 BRAKE WHEEL CYLINDER REAR LH
464		3502060-02 ZYD08BK-BWCJC 3502060-02	ZYOTE 2008 BRAKE WHEEL CYLINDER REAR RH



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
465		2904102-02 ZYD08BK-BUAI1 2904102-02	ZYOTE 2008 BOLT FOR UNDER ARM FRONT
466		2904101-02 ZYD08BK-BUAI0 2904101-02	ZYOTE 2008 BOLT FOR UNDER ARM FRONT
467		4001120-02A2 ZYD08BK-BTYWH 4001120-02A2	ZYOTE 2008 BATTERY WIRING HARNESS
468		3703020-02 ZYD08BK-BTP0 3703020-02	ZYOTE 2008 BATTERY PLATE
469		4134020-02 ZYD08BK-BSC0A 4134020-02	ZYOTE 2008 BRAKE LAMP SWITCH ASSY
470		3105010-02 ZYD08BK-BRKSU 3105010-02	ZYOTE 2008 SPARE WHEEL BRACKET
471		3411112-02 ZYD08BK-BRKSU 3411112-02	ZYOTE 2008 STEERING GEAR BRACKET
472		3407015-02 ZYD08BK-BRKSU 3407015-02	ZYOTE 2008 BRACKET FOR STEERING PUMP AND COMPRESOR



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
473		1605120-02 ZYD08BK-BRKMC 1605120-02	ZYOTE 2008 BRACKET FOR OIL CUP-CLUTCH MASTER CYLINDER
474		2803024-02 ZYD08BK-BRKDF 2803024-02	ZYOTE 2008 BRACKET LH FOR FRONT BUMPER
475		471Q-1L-100313 ZYD08BK-BRKCS0 471Q-1L-100313	ZYOTE 2008 CAMSHAFT POSITION SENSOR 1.3- 1.6L BRACKET
476		2803026-02 ZYD08BK-BRKCF 2803026-02	ZYOTE 2008 BRACKET RH FOR FRONT BUMPER
477		1109120-02 ZYD08BK-BRKAF 1109120-02	ZYOTE 2008 AIR FILTER N.1 FIX BRACKET
478		471Q-1000040 ZYD08BK-BRK2 471Q-1000040	ZYOTE 2008 GENERATOR BRACKET
479		1108011-02 ZYD08BK-BRK1 1108011-02	ZYOTE 2008 NO 1 BRACKET FOR SPEEDUP CABLE
480		1104112-02 ZYD08BK-BRK0 1104112-02	ZYOTE 2008 NO2 BRACKET FOR FUEL DELIVER



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
481		2810111-02 ZYD08BK-BOTSF1 2810111-02	ZYOTE 2008 SUB FRAME BOLT
482		2810112-02 ZYD08BK-BOTSF 2810112-02	ZYOTE 2008 SUB FRAME BOLT
483		471Q-1000810 ZYD08BK-BOTCH 471Q-1000810	ZYOTE 2008 BOLT OF CYLINDER HEAD ASSY
484		471Q-1007007 ZYD08BK-BOTBC 471Q-1007007	ZYOTE 2008 ADJUST SCREW, VALVE CLERARNCE
485		3703041-02 ZYD08BK-BOT8 3703041-02	ZYOTE 2008 FIXING LONG BOLT
486		471Q-0401428 ZYD08BK-BOT7 471Q-0401428	ZYOTE 2008 BOLT, DOUBLE DIRECTION THREAD 1.3-1.6L
487		471Q-1003010 ZYD08BK-BOT6 471Q-1003010	ZYOTE 2008 BOLT, DOUBLE DIRECTION THREAD 1.3-1.6L
488		471Q-1003009 ZYD08BK-BOT5 471Q-1003009	ZYOTE 2008 BOLT, DOUBLE DIRECTION THREAD 1.3-1.6L



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
489		Q1461020X1,25 ZYD08BK-BOT4 Q1461020X1,25	ZYOTE 2008 BOLT
490		2804012-02 ZYD08BK-BOT3 2804012-02	ZYOTE 2008 BOLT
491		471Q-0140268 ZYD08BK-BOT2 471Q-0140268	ZYOTE 2008 BOLT
492		Q1460612 ZYD08BK-BOT1 Q1460612	ZYOTE 2008 BOLT
493		3540110-02 ZYD08BK-BOS0A 3540110-02	ZYOTE 2008 VACUUM BOOSTER ASSY
494		84020325-02 ZYD08BK-BOCB 84020325-02	ZYOTE 2008 BONNET LOCK CABLE ASSY
495		8402035-02 ZYD08BK-BOCA 8402035-02	ZYOTE 2008 BONNET LOCK CABLE ASSY
496		8402012-02 ZYD08BK-BNTFN 8402012-02	ZYOTE 2008 FIXING NIP, BONNET KNIGHTHEAD



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
497		8402011-02 ZYD08BK-BNT0 8402011-02	ZYOTE 2008 BONNET KNIGHTHEAD
498		8402025-02 ZYD08BK-BNNIS 8402025-02	ZYOTE 2008 BONNET FRONT SEAL BAR
499		8402100-02 ZYD08BK-BNNO 8402100-02	ZYOTE 2008 BONNET
500		3540100-02 ZYD08BK-BMCVB 3540100-02	ZYOTE 2008 BRAKE MASTER CYLINDER AND VACUUM BOOSTER ASSY
501		3504100-02 ZYD08BK-BMCCP 3504100-02	ZYOTE 2008 BRAKE MASTER CYLINDER AND CLUTCH PEDAL ASSY
502		2916016-02 ZYD08BK-BLW0 2916016-02	ZYOTE 2008 BALANCE WEIGHT
503		8402010-02 ZYD08BK-BLK0 8402010-02	ZYOTE 2008 BONNET LOCK ASSY
504		3540210-02 ZYD08BK-BKP0 3540210-02	ZYOTE 2008 BRAKE PUMP ASSY (WITHOUT OIL CUP)



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
505		3502120A02 ZYD08BK-BKHJ1 3502120A02	ZYOTE 2008 BRAKE HUB REAR WITH ABS
506		3502120-02 ZYD08BK-BKHJ0 3502120-02	ZYOTE 2008 BRAKE HUB REAR
507		1001035 ZYD08BK-BDV1 1001035	ZYOTE 2008 BOLT FOR DRIVE SHAFT RACK
508		2201127-02 ZYD08BK-BDV0 2201127-02	ZYOTE 2008 BOLT FOR TRANSMISION SHAFT
509		3001104-02 ZYD08BK-BDC0 3001104-02	ZYOTE 2008 BRAKE DISC
510		471Q-1002005 ZYD08BK-BCH1 471Q-1002005	ZYOTE 2008 BOLT FOR CRANKSHAFT BEARING CAP
511		471Q-1000011-B ZYD08BK-BCH0 471Q-1000011-B	ZYOTE 2008 BOLT FOR CRANKSHAFT
512		471Q-1002004 ZYD08BK-BC12 471Q-1002004	ZYOTE 2008 MIDDLE MAIN BEARING CAP NO.4



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
513		471Q-1002003 ZYD08BK-BC11 471Q-1002003	ZYOTE 2008 MIDDLE MAIN BEARING CAP
514		471Q-1002002 ZYD08BK-BC10 471Q-1002002	ZYOTE 2008 CRANKSHAFT MAIN BEARING CAP
515		2804011-02 ZYD08BK-BBU0 2804011-02	ZYOTE 2008 REAR BUMPER
516		3540230-02 ZYD08BK-B341 3540230-02	ZYOTE 2008 SAVE OIL CUP FOR BRAKE PUMP ASSY
517		1605110-02 ZYD08BK-B340 1605110-02	ZYOTE 2008 OIL CUP ASSY FOR CLUTCH MASTER CYLINDER
518		SC72-1802506 ZYD08BK-B01G SC72-1802506	ZYOTE 2008 LUTATION DUSTPROOF GUIDE BUSH
519		471Q-1014012 ZYD08BK-ARH1 471Q-1014012	ZYOTE 2008 AIR HOSE
520		471Q-1-1014012 ZYD08BK-ARH0 471Q-1-1014012	ZYOTE 2008 AIR HOSE



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
521		7903010-02 ZYD08BK-ANT0 7903010-02	ZYOTE 2008 ANTENNA
522		1109112-02 ZYD08BK-AFE1 1109112-02	ZYOTE 2008 AIR FILTER ELEMENTS
523		1109100-02 ZYD08BK-AFE0 1109100-02	ZYOTE 2008 AIR FILTER ASSY
524		8103010-02 ZYD08BK-ACSA 8103010-02	ZYOTE 2008 COMPRESSOR ASSY
525		1108200-02 ZYD08BK-ACL0A 1108200-02	ZYOTE 2008 SPEEDUP CABLE ASSY
526		2400100A02 ZYD08BK-ABR6A 2400100A02	ZYOTE 2008 1.6L REAR AXLE AND BRAKE ASSY WITH ABS
527		2400100-02 ZYD08BK-ABR6 2400100-02	ZYOTE 2008 1.6L REAR AXLE AND BRAKE ASSY
528		2400100A03 ZYD08BK-ABR3A 2400100A03	ZYOTE 2008 1.3L REAR AXLE AND BRAKE ASSY WITH ABS



BEN-YA INDUSTRIAL CO., LTD.

4F, NO.16, LANE 181, SEC.2, JIUZONG ROAD Taipei, Taiwan, R.O.C.
TEL: 886-2-27990822 FAX: 886-2-27978753 e-mail: benya@ms24.hinet.net

ZYOTE CATALOGUE

Date: 2022/09/06

SEQ.	PHOTO	OEM_NO/ITEM_NO/CODE	DESCRIPTION
529		2400100-03 ZYD08BK-ABR3 2400100-03	ZYOTE 2008 1.3L REAR AXLE AND BRAKE ASSY